DTC U3000:42 [CONNECTIVITY MASTER UNIT]

id0902n7106700

Description	Connectivity master unit (CMU) internal malfunction (poor data read-outs)
Detection condition	• The connectivity master unit (CMU) cannot read data from the NVRAM in the connectivity master unit (CMU) with the ignition switched to ACC or ON (engine off or on).
Fail-safe	Not applicable
Possible cause	• Connectivity master unit (CMU) malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY IF MALFUNCTIONING LOCATION IS CONNECTIVITY MASTER UNIT (CMU) DEPENDING ON REPEATABILITY** • Clear the DTC for the connectivity master unit (CMU) using the M-MDS. (See CLEARING DTC [CONNECTIVITY MASTER UNIT].) • Switch the ignition ON (engine off or on) and wait for **7 s or more**. • Retrieve the connectivity master unit (CMU) DTCs using the M-MDS. (See DTC INSPECTION [CONNECTIVITY MASTER UNIT].) • Is the same DTC displayed?	Yes	Replace the connectivity master unit (CMU), then go to the next step. (See CONNECTIVITY MASTER UNIT (CMU) REMOVAL/INSTALLATION.)
		No	Go to the next step.
2	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [CONNECTIVITY MASTER UNIT].)
		No	DTC troubleshooting completed.