DTC INSPECTION [CONNECTIVITY MASTER UNIT]

id0902n7345400

When using M-MDS

1. Connect the M-MDS to the DLC-2.
2. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.
   (1) Select “Self Test”.
   (2) Select “All CMDTCs”.
3. Verify the DTC according to the directions on the screen.
   - If any DTCs are displayed, perform troubleshooting according to the corresponding DTC inspection.
4. After completion of repairs, clear all DTCs stored in the connectivity master unit (CMU). (See CLEARING DTC [CONNECTIVITY MASTER UNIT].)

When using Diagnostic Assist Function

DTC inspection can also be performed by launching the diagnostic assist function of the connectivity master unit (CMU). (See DIAGNOSTIC ASSIST FUNCTION [CONNECTIVITY MASTER UNIT].)