DTC TABLE [CONNECTIVITY MASTER UNIT]

id0902n7347100

×: Applicable
—: Not applicable

DTC No.	Diagnostic assist code*1	Warning/ indicator lights	Description	Fail-safe	Drive cycle	Self test type*2	Memory function	Page
B100E:87*3	03/04	—	Communication error with DVD/ CD player	—	—	C	×	(See DTC B100E:87 [CONNECTIVITY MASTER UNIT].)
B1087:87	03/04	—	Communication error with commander switch	—	—	C	×	(See DTC B1087:87 [CONNECTIVITY MASTER UNIT].)
B108E:04	03/04	—	Center display internal malfunction	—	—	C	×	(See DTC B108E:04 [CONNECTIVITY MASTER UNIT].)
B108E:06	03/04	—	HDCP authorization error	—	—	C	×	(See DTC B108E:06 [CONNECTIVITY MASTER UNIT].)
B108E:1C	03/04	—	Low power supply voltage input to center display	×	—	C	×	(See DTC B108E:1C [CONNECTIVITY MASTER UNIT].)
B108E:87	03/04	—	Center display circuit malfunction	—	—	C	×	(See DTC B108E:87 [CONNECTIVITY MASTER UNIT].)
B116A:11	03/04	—	Microphone circuit malfunction	—	—	C	×	(See DTC B116A:11 [CONNECTIVITY MASTER UNIT].)
B116A:12	03/04	—	Microphone circuit malfunction	—	—	C	×	(See DTC B116A:12 [CONNECTIVITY MASTER UNIT].)
B116A:92	03/04	—	Microphone circuit malfunction	—	—	C	×	(See DTC B116A:92 [CONNECTIVITY MASTER UNIT].)
B119F:11	03/04	—	GPS antenna circuit malfunction	—	—	C	×	(See DTC B119F:11 [CONNECTIVITY MASTER UNIT].)
B119F:13	03/04	—	GPS antenna circuit malfunction	—	—	C	×	(See DTC B119F:13 [CONNECTIVITY MASTER UNIT].)
B119F:1D	03/04	—	GPS antenna circuit malfunction	—	—	C	×	(See DTC B119F:1D [CONNECTIVITY MASTER UNIT].)
B119F:92	03/04	—	GPS antenna circuit malfunction	—	—	C	×	(See DTC B119F:92 [CONNECTIVITY MASTER UNIT].)
B11BA:11	03/04	—	Steering switch circuit malfunction	—	—	C	×	(See DTC B11BA:11 [CONNECTIVITY MASTER UNIT].)
B11BA:15	03/04	—	Steering switch circuit malfunction	—	—	C	×	(See DTC B11BA:15 [CONNECTIVITY MASTER UNIT].)
B1201:11	03/04	—	Steering switch circuit malfunction	—	—	C	×	(See DTC B1201:11 [CONNECTIVITY MASTER UNIT].)
B1201:15	03/04	—	Steering switch circuit malfunction	—	—	C	×	(See DTC B1201:15 [CONNECTIVITY MASTER UNIT].)
B1238:01	03/05	—	Speaker circuit malfunction	—	—	C	×	(See DTC B1238:01 [CONNECTIVITY MASTER UNIT].)

DTC No.	Diagnostic assist code*1	Warning/ indicator lights	Description	Fail-safe	Drive cycle	Self test type*2	Memory function	Page
B1238:16	03/05	—	Tuner and amp unit (TAU) low power supply voltage input	—	—	C	×	(See DTC B1238:16 [CONNECTIVITY MASTER UNIT].)
B1238:87	03/04	—	RDS traffic information transfer circuit malfunction	—	—	C	×	(See DTC B1238:87 [CONNECTIVITY MASTER UNIT].)
B1252:09	03/04	—	Auxiliary jack/USB port/SD card slot hub circuit malfunction	—	—	C	×	(See DTC B1252:09 [CONNECTIVITY MASTER UNIT].)
B1252:1D	03/04	—	Auxiliary jack/USB port/SD card slot hub circuit malfunction	—	—	C	×	(See DTC B1252:1D [CONNECTIVITY MASTER UNIT].)
B1252:87	03/04	—	Communication error with auxiliary jack/USB port/SD card slot hub	—	—	C	×	(See DTC B1252:87 [CONNECTIVITY MASTER UNIT].)
B12BD:11*3	03/04	—	Rear mount camera circuit malfunction	—	—	C	×	(See DTC B12BD:11 [CONNECTIVITY MASTER UNIT].)
B12BD:87*4	03/04	—	Rear mount camera transmission error	—	—	C	×	(See DTC B12BD:87 [CONNECTIVITY MASTER UNIT].)
B1A89:13 *5	03/05	—	DAB antenna feeder malfunction	—	—	C	×	(See DTC B1A89:13 [CONNECTIVITY MASTER UNIT].)
B1A89:42 *5	03/05	—	Tuner and amp unit internal malfunction	—	—	C	×	(See DTC B1A89:42 [CONNECTIVITY MASTER UNIT].)
B1D19:00 *3	03/06	—	Region code error or parental lock function error	—	—	C	×	(See DTC B1D19:00 [CONNECTIVITY MASTER UNIT].)
B1D19:64 *6	03/06	—	Incompatible disc inserted	×	—	C	×	(See DTC B1D19:64 [CONNECTIVITY MASTER UNIT].)
B1D19:79 *6	03/06	—	CD player or DVD/CD player disc read error	×	—	C	×	(See DTC B1D19:79 [CONNECTIVITY MASTER UNIT].)
B1D19:98 *6	03/06	—	Abnormal CD player or DVD/CD player temperature	×	—	C	×	(See DTC B1D19:98 [CONNECTIVITY MASTER UNIT].)
U0001:88	03/04	—	Module communication error (HS-CAN)	—	—	C	×	(See DTC U0001:88/ U0100:00/U0101:00/ U0121:00/U0131:00/ U0140:00/U0151:00/ U0155:00/U0182:00/ U0214:00/U0235:00/ U023A:00 [CONNECTIVITY MASTER UNIT].)
U0028:88	03/04	—	Unit communication error (LOCAL-CAN)	—	—	C	×	(See DTC U0028:88 [CONNECTIVITY MASTER UNIT].)

DTC No.	Diagnostic assist code*1	Warning/ indicator lights	Description	Fail-safe	Drive cycle	Self test type*2	Memory function	Page
U0100:00	03/04	—	Communication error with PCM	—	—	C	×	(See DTC U0001:88/ U0100:00/U0101:00/ U0121:00/U0131:00/ U0140:00/U0151:00/ U0155:00/U0182:00/ U0214:00/U0235:00/ U023A:00 [CONNECTIVITY MASTER UNIT].)
U0101:00 *7	03/04	—	Communication error with TCM	—	—	C	×	
U0121:00	03/04	—	Communication error with ABS HU/CM or DSC HU/CM	—	—	C	×	
U0131:00	03/04	—	Communication error with EPS control module	—	—	C	×	
U0140:00	03/04	—	Communication error with BCM	—	—	C	×	
U0151:00	03/04	—	Communication error with SAS control module	—	—	C	×	
U0155:00	03/04	—	Communication error with instrument cluster	—	—	C	×	
U0182:00 *8	03/04	—	Communication error with auto leveling control module	—	—	C	×	
U0184:00	03/04	—	Communication error with tuner and amp unit (TAU)	—	—	C	×	(See DTC U0184:00/ U0187:00 [CONNECTIVITY MASTER UNIT].)
U0187:00 *6	03/04	—	Communication error with CD player or DVD/CD player	—	—	C	×	
U0214:00	03/04	—	Communication error with start stop unit	—	—	C	×	(See DTC U0001:88/ U0100:00/U0101:00/ U0121:00/U0131:00/ U0140:00/U0151:00/ U0155:00/U0182:00/ U0214:00/U0235:00/ U023A:00 [CONNECTIVITY MASTER UNIT].)
U0235:00 *9	03/04	—	Communication error with laser sensor	—	—	C	×	
U023A:00*10	03/04	—	Communication error with forward sensing camera (FSC)	—	—	C	×	
U2300:54	03/04	—	Configuration data not received from instrument cluster	—	—	C	×	(See DTC U2300:54 [CONNECTIVITY MASTER UNIT].)
U2300:55	03/04	—	Instrument cluster configuration not implemented	—	—	C	×	(See DTC U2300:55 [CONNECTIVITY MASTER UNIT].)
U3000:42	03/04	—	Connectivity master unit (CMU) internal malfunction (poor data read-outs)	—	—	C	×	(See DTC U3000:42 [CONNECTIVITY MASTER UNIT].)
U3003:16	03/04	—	Low ACC power supply voltage input to connectivity master unit (CMU)	—	—	C	×	(See DTC U3003:16 [CONNECTIVITY MASTER UNIT].)

*1 : The double-digit number indicates the diagnostic assist code with which DTCs can be detected during the DTC inspection using the diagnostic assist function.(See DIAGNOSTIC ASSIST FUNCTION [CONNECTIVITY MASTER UNIT].)

*2 : C: CMDTC self test, D:ODDTC self test

*3 : With DVD/CD player

*4 : With rear mount camera

*5 : With DAB antenna amplifier

*6 : With CD player or DVD/CD player

*7 : ATX

*8 : With headlight auto levelling system

*9 : With smart city brake support (SCBS)

*10 : With forward sensing camera (FSC)