CLEARING DTC [CONNECTIVITY MASTER UNIT]

id0902n7400300

When using M-MDS

1. Connect the M-MDS to the DLC-2.
2. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.
   (1) Select “Self Test”.
   (2) Select “All CMDTCs”.
3. Verify the DTC according to the directions on the screen.
4. Press the clear button on the DTC screen to clear the DTC.
5. Switch the ignition off.
6. Switch the ignition ON (engine off or on) and wait for **5 s or more**.
7. Perform DTC inspection. (See DTC INSPECTION [CONNECTIVITY MASTER UNIT].)
8. Verify that no DTCs are displayed.

When using Diagnostic Assist Function

Clearing DTC can also be performed by launching the diagnostic assist function of the connectivity master unit (CMU). (See DIAGNOSTIC ASSIST FUNCTION [CONNECTIVITY MASTER UNIT].)