DTC B13D3:4A [START STOP UNIT]

id0902p6020800

Description	Remote transmitter matching malfunction
Detection condition	• Start stop unit detects a remote transmitter different from the one equipped to the vehicle.
Fail-safe	Not applicable
Possible cause	• Mistaken remote transmitter registration • Start stop unit configuration error • Remote transmitter malfunction • Start stop unit malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY THAT THE VEHICLE AND REMOTE TRANSMITTER COMBINATION IS CORRECT** • Verify that the vehicle and remote transmitter combination is correct. • Is the combination of the remote transmitters correct?	Yes	Go to the next step.
		No	Re-register using the correct remote transmitters, then go to the Step 4. (See IMMOBILIZER SYSTEM-RELATED PARTS PROGRAMMING.)
2	**PERFORM START STOP UNIT CONFIGURATION (USING AS-BUILT DATA)** • Using the M-MDS, perform the start stop unit configuration (using As-Built data). (See START STOP UNIT CONFIGURATION (USING AS-BUILT DATA).) • Clear the DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) • Retrieve the start stop unit DTCs using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) • Is the same DTC displayed?	Yes	Using the M-MDS, perform the start stop unit configuration (using As-Built data) again, then go to the next step. (See START STOP UNIT CONFIGURATION (USING AS-BUILT DATA).)
		No	Go to Step 5.
3	**DETERMINE MALFUNCTIONING KEY DEPENDING ON REPEATABILITY** **Note** • Perform the following procedure for all of the programmed remote transmitters. • Clear the DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) • Retrieve the start stop unit DTCs using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) • Is there a remote transmitter which indicates the same DTC?	Yes	Replace the remote transmitter which indicates the DTC, then go to the next step. (See IMMOBILIZER SYSTEM-RELATED PARTS PROGRAMMING.)
		No	Go to the next step.
4	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) • Retrieve the start stop unit DTCs using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) • Is the same DTC displayed?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the start stop unit. (See START STOP UNIT REMOVAL/INSTALLATION.) Go to the next step.
		No	Go to the next step.

Step	Inspection		Action
5	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [START STOP UNIT].)
		No	DTC troubleshooting completed.