DTC B13D3:97 [START STOP UNIT]

id0902p6020900

Description	Remote transmitter registration work not completed
Detection condition	• Start stop unit detects that the registration of a remote transmitter has not been completed.
Fail-safe	Not applicable
Possible cause	• DTCs are stored in the immobilizer system. • Remote transmitter registration not completed correctly. • Start stop unit configuration error • Start stop unit malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY IMMOBILIZER SYSTEM DTCs** • Retrieve the immobilizer system DTCs using the M-MDS. (See DTC INSPECTION [IMMOBILIZER SYSTEM].) • Are any DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [IMMOBILIZER SYSTEM].)
		No	Go to the next step.
2	**REGISTER REMOTE TRANSMITTER** • Register the remote transmitter. (See IMMOBILIZER SYSTEM-RELATED PARTS PROGRAMMING.) • Clear the DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) • Retrieve the start stop unit DTCs using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) • Is the same DTC displayed?	Yes	Go to the next step.
		No	Go to Step 5.
3	**PERFORM START STOP UNIT CONFIGURATION (USING AS-BUILT DATA)** • Using the M-MDS, perform the start stop unit configuration (using As-Built data). (See START STOP UNIT CONFIGURATION (USING AS-BUILT DATA).) • Clear the DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) • Retrieve the start stop unit DTCs using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) • Is the same DTC displayed?	Yes	Using the M-MDS, perform the start stop unit configuration (using As-Built data) again, then go to the next step. (See START STOP UNIT CONFIGURATION (USING AS-BUILT DATA).)
		No	Go to Step 5.
4	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) • Retrieve the start stop unit DTCs using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) • Is the same DTC displayed?	Yes	Replace the start stop unit, then go to the next step. (See START STOP UNIT REMOVAL/INSTALLATION.)
		No	Go to the next step.
5	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [START STOP UNIT].)
		No	DTC troubleshooting completed.