DTC C0051:95 [START STOP UNIT]

id0902p6027700

Description	Steering angle sensor assembly malfunction
Detection condition	• Start stop unit receives the following signals with the ignition switched ON (engine off or on). — Steering angle sensor assembly malfunction from EPS control module for **1 s or more** — Improper assembly of steering angle sensor at **360°** — Steering wheel angle of **720° or more** for **0.048 s or more**
Fail-safe	Not applicable
Possible cause	• DTCs are stored in the EPS control module. • Improper assembly of steering angle sensor • Start stop unit malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY EPS CONTROL MODULE DTCs** • Retrieve the EPS control module DTCs using the M-MDS. (See DTC INSPECTION [EPS CONTROL MODULE].) • Are any DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [EPS CONTROL MODULE].)
		No	Go to the next step.
2	**VERIFY STEERING ANGLE SENSOR INSTALLATION CONDITION** • Verify the steering angle sensor installation condition. (See CLOCK SPRING INSPECTION [STANDARD DEPLOYMENT CONTROL SYSTEM].) (See CLOCK SPRING INSPECTION [TWO-STEP DEPLOYMENT CONTROL SYSTEM].) • Is the steering angle sensor installed correctly?	Yes	Go to the next step.
		No	Install the steering angle sensor correctly, then go to the next step. (See CLOCK SPRING REMOVAL/INSTALLATION [STANDARD DEPLOYMENT CONTROL SYSTEM].) (See CLOCK SPRING REMOVAL/INSTALLATION [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
3	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) • Switch the ignition ON (engine off or on) and wait for **1 s or more**. • Retrieve the start stop unit DTCs using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) • Is the same DTC displayed?	Yes	Replace the start stop unit, then go to the next step. (See START STOP UNIT REMOVAL/INSTALLATION.)
		No	Go to the next step.
4	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [START STOP UNIT].)
		No	DTC troubleshooting completed.