## DTC INSPECTION [ADVANCED KEYLESS ENTRY SYSTEM]

id0902p8025800

**CMDTC Self Test**

1. Connect the M-MDS to the DLC-2.
2. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.
   (1) Select “Self Test”.
   (2) Select “All CMDTCs”.
3. Verify the DTC according to the directions on the screen.
   - If any DTCs are displayed, perform troubleshooting according to the corresponding DTC inspection.
4. After completion of repairs, clear all DTCs stored in the start stop unit. (See CLEARING DTC [ADVANCED KEYLESS ENTRY SYSTEM].)

**ODDTC Self Test**

1. Connect the M-MDS to the DLC-2.
2. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.
   (1) Select “Self Test”.
   (2) Select “Modules”.
   (3) Select “SSU”.
3. Verify the DTC according to the directions on the screen.
   - If any DTCs are displayed, perform troubleshooting according to the corresponding DTC inspection.
4. After completion of repairs, clear all DTCs stored in the start stop unit. (See CLEARING DTC [ADVANCED KEYLESS ENTRY SYSTEM].)