DTC TABLE [FORWARD SENSING CAMERA (FSC)]

id0902p9029400

×: Applicable
—: Not applicable

DTC No.	LDWS warning light	Description	Fail-safe	Drive cycle	Self test type*1	Memory function	Page
B115E:54	Illuminated	Forward sensing camera (FSC) aiming not completed	×	—	C, D	×	(See DTC B115E:54 [FORWARD SENSING CAMERA (FSC)].)
B13A6:11	Illuminated	LDWS switch circuit malfunction	×	—	C, D	×	(See DTC B13A6:11 [FORWARD SENSING CAMERA (FSC)].)
C1001:92	Illuminated	Poor functioning of forward sensing camera (FSC)	×	—	C, D	×	(See DTC C1001:92 [FORWARD SENSING CAMERA (FSC)].)
C1001:97	Illuminated	Forward sensing camera (FSC) poor visibility	×	—	C, D	×	(See DTC C1001:97 [FORWARD SENSING CAMERA (FSC)].)
U0001:88	Illuminated	Module communication error (HS-CAN)	×	—	C, D	×	(See DTC U0001:88/ U0100:00/U0121:00/ U0131:00/U0140:00/ U0155:00/U0214:00 [FORWARD SENSING CAMERA (FSC)].)
U0100:00	Illuminated	Communication error with PCM	×	—	C, D	×	
U0121:00	Illuminated	Communication error with DSC HU/CM	×	—	C, D	×	
U0131:00	Illuminated	Communication error with EPS control module	×	—	C, D	×	
U0140:00	Illuminated	Communication error with BCM	×	—	C, D	×	
U0155:00	Illuminated	Communication error with instrument cluster	×	—	C, D	×	
U0214:00	Illuminated	Communication error with start stop unit	×	—	C, D	×	
U0401:68	Illuminated	Error signal received from PCM	×	—	C, D	×	(See DTC U0401:68 [FORWARD SENSING CAMERA (FSC)].)
U0415:68	Illuminated	Error signal received from DSC HU/CM	×	—	C, D	×	(See DTC U0415:68 [FORWARD SENSING CAMERA (FSC)].)
U0420:68	Illuminated	Error signal received from EPS control module	×	—	C, D	×	(See DTC U0420:68 [FORWARD SENSING CAMERA (FSC)].)
U0423:68	Illuminated	Error signal received from instrument cluster	×	—	C, D	×	(See DTC U0423:68 [FORWARD SENSING CAMERA (FSC)].)
U0515:68	Illuminated	Error signal received from start stop unit	×	—	C, D	×	(See DTC U0515:68 [FORWARD SENSING CAMERA (FSC)].)
U2005:86	Illuminated	Error signal received from PCM	×	—	C, D	×	(See DTC U2005:86 [FORWARD SENSING CAMERA (FSC)].)
U2100:00	Illuminated	Forward sensing camera (FSC) configuration error	×	—	C, D	×	(See DTC U2100:00 [FORWARD SENSING CAMERA (FSC)].)

DTC No.	LDWS warning light	Description	Fail-safe	Drive cycle	Self test type*1	Memory function	Page
U2101:00	Illuminated	Forward sensing camera (FSC) configuration error	×	—	C, D	×	(See DTC U2101:00 [FORWARD SENSING CAMERA (FSC)].)
U3000:04	Illuminated	Forward sensing camera (FSC) internal malfunction	×	—	C, D	×	(See DTC U3000:04/ U3000:09/U3000:42/ U3000:49 [FORWARD SENSING CAMERA (FSC)].)
U3000:09	Illuminated	Forward sensing camera (FSC) internal malfunction	×	—	C, D	×	
U3000:42	Illuminated	Forward sensing camera (FSC) internal malfunction	×	—	C, D	×	
U3000:49	Illuminated	Forward sensing camera (FSC) internal malfunction	×	—	C, D	×	
U3003:16	Illuminated	Forward sensing camera (FSC) low power supply voltage input	×	—	C, D	×	(See DTC U3003:16 [FORWARD SENSING CAMERA (FSC)].)
U3003:17	Illuminated	Forward sensing camera (FSC) high power supply voltage input	×	—	C, D	×	(See DTC U3003:17 [FORWARD SENSING CAMERA (FSC)].)

*1 : C: CMDTC self test, D: ODDTC self test