DTC B115E:54 [FORWARD SENSING CAMERA (FSC)]

id0902p9029500

Description	Forward sensing camera (FSC) aiming not completed
Detection condition	• Forward sensing camera (FSC) aiming not completed is detected.
Fail-safe	• Inhibits the lane departure warning system (LDWS). • Inhibits the high beam control (HBC) system.
Possible cause	• Forward sensing camera (FSC) aiming not performed. • Forward sensing camera (FSC) malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**PERFORM FORWARD SENSING CAMERA (FSC) AIMING** • Perform the forward sensing camera (FSC) aiming. (See FORWARD SENSING CAMERA (FSC) AIMING.) • Clear the DTC for the forward sensing camera (FSC) using the M-MDS. (See CLEARING DTC [FORWARD SENSING CAMERA (FSC)].) • Retrieve the forward sensing camera (FSC) DTCs using the M-MDS. (See DTC INSPECTION [FORWARD SENSING CAMERA (FSC)].) • Is the same DTC displayed?	Yes	Perform the forward sensing camera (FSC) aiming again, then go to the next step. (See FORWARD SENSING CAMERA (FSC) AIMING.)
		No	Go to Step 3.
2	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the forward sensing camera (FSC) using the M-MDS. (See CLEARING DTC [FORWARD SENSING CAMERA (FSC)].) • Retrieve the forward sensing camera (FSC) DTCs using the M-MDS. (See DTC INSPECTION [FORWARD SENSING CAMERA (FSC)].) • Is the same DTC displayed?	Yes	Replace the forward sensing camera (FSC), then go to the next step. (See FORWARD SENSING CAMERA (FSC) REMOVAL/INSTALLATION.)
		No	Go to the next step.
3	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FORWARD SENSING CAMERA (FSC)].)
		No	DTC troubleshooting completed.