DTC B13A6:11 [FORWARD SENSING CAMERA (FSC)]

id0902p9029600

Description	LDWS switch circuit malfunction
Detection condition	• Forward sensing camera (FSC) detects that LDWS switch is held pressed for **10 s or more**.
Fail-safe	• Inhibits the lane departure warning system (LDWS).
Possible cause	• DTCs are stored in the instrument cluster. — Instrument cluster malfunction • LDWS switch malfunction • Forward sensing camera (FSC) malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY INSTRUMENT CLUSTER DTCs** • Retrieve the instrument cluster DTCs using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].) • Are any DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [INSTRUMENT CLUSTER].)
		No	Go to the next step.
2	**INSPECT LDWS SWITCH** • Inspect the LDWS switch. (See LDWS SWITCH INSPECTION.) • Is the LDWS switch normal?	Yes	Go to the next step.
		No	Replace the cluster switch, then go to the next step. (See CLUSTER SWITCH REMOVAL/INSTALLATION.)
3	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the forward sensing camera (FSC) using the M-MDS. (See CLEARING DTC [FORWARD SENSING CAMERA (FSC)].) • Switch the ignition ON (engine off or on) and wait for **11.5 s or more**. • Retrieve the forward sensing camera (FSC) DTCs using the M-MDS. (See DTC INSPECTION [FORWARD SENSING CAMERA (FSC)].) • Is the same DTC displayed?	Yes	Replace the forward sensing camera (FSC), then go to the next step. (See FORWARD SENSING CAMERA (FSC) REMOVAL/INSTALLATION.)
		No	Go to the next step.
4	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FORWARD SENSING CAMERA (FSC)].)
		No	DTC troubleshooting completed.