DTC C1001:97 [FORWARD SENSING CAMERA (FSC)]

id0902p9029800

Description	Forward sensing camera (FSC) poor visibility
Detection condition	• With the LDWS switch on or the high beam control (HBC) system operating, the forward sensing camera (FSC) detects that its field of view is obstructed for a certain period of time.
Fail-safe	• Inhibits the lane departure warning system (LDWS). • Inhibits the high beam control (HBC) system.
Possible cause	• Windshield is dirty • Forward sensing camera (FSC) lens is dirty • Forward sensing camera (FSC) malfunction • Frosted windshield • Nighttime, roads without street lights or reflective objects
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY WINDSHIELD DIRT** • Verify if the windshield is dirty. • Is the windshield dirty?	Yes	Clean the windshield, then go to Step 3.
		No	Go to the next step.
2	**VERIFY FORWARD SENSING CAMERA (FSC) LENS DIRT** • Verify if the forward sensing camera (FSC) lens is dirty. • Is the forward sensing camera (FSC) lens dirty?	Yes	Clean the forward sensing camera (FSC) lens, then go to the next step.
		No	Go to the next step.
3	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the forward sensing camera (FSC) using the M-MDS. (See CLEARING DTC [FORWARD SENSING CAMERA (FSC)].) • Drive the vehicle at a vehicle speed of **20 km/h {12 mph} or more** for **3 min or more**. • Retrieve the forward sensing camera (FSC) DTCs using the M-MDS. (See DTC INSPECTION [FORWARD SENSING CAMERA (FSC)].) • Is the same DTC displayed?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the forward sensing camera (FSC). (See FORWARD SENSING CAMERA (FSC) REMOVAL/INSTALLATION.) Go to the next step.
		No	Go to the next step.
4	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FORWARD SENSING CAMERA (FSC)].)
		No	DTC troubleshooting completed.