PID/DATA MONITOR TABLE [FORWARD SENSING CAMERA (FSC)]

id0902p9032600

PID	Unit/ Operation	Data contents	Module control terminal
A_ANG_PITCH	° (deg)	Displays vanishing point correction angle (pitch) corrected by forward sensing camera (FSC) when performing forward sensing camera (FSC) aiming using M-MDS.	C, E (CAN)
A_ANG_ROLL	° (deg)	Displays vanishing point correction angle (roll) corrected by forward sensing camera (FSC) when performing forward sensing camera (FSC) aiming using M-MDS.	C, E (CAN)
A_ANG_YAW	° (deg)	Displays vanishing point correction angle (yaw) corrected by forward sensing camera (FSC) when performing forward sensing camera (FSC) aiming using M-MDS.	C, E (CAN)
BRAKE_SW	Off/On	• Off: Brake switch (No. 2 signal) is off. (Brake pedal is not depressed.) • On: Brake switch (No. 2 signal) is on. (Brake pedal is depressed.)	C, E (CAN)
DSP_LANE_ST	Off/ Dash_Lane/ Solid_Lane	• Off: Lane departure warning system (LDWS) is off. • Dash_Lane: When any one of the following conditions is met: — Actual vehicle speed is less than vehicle speed for operation of lane departure warning system (LDWS). — Dirt or fogging of camera is detected. — Vehicle lane lines are not recognized. • Solid_Lane: Vehicle lane lines are recognized at a vehicle speed of **40 km/h {25 mph} or more**.	C, E (CAN)
DSP_WRN_ST	Off/ LDWS_Left/ LDWS_Right/ LDWS_Fail/ HBC_Fail/ Camera_BLK/FOW Warning/ Fow Fail/ FSC_Fail/ Camera_DRDT	• Off: When any one of the following conditions is met: — LDWS switch is off. — Lane departure warning system (LDWS) does not determine warning. — Forward sensing camera (FSC) does not detect malfunction. • LDWS_Left: Lane departure on vehicle left side is detected. • LDWS_Right: Lane departure on vehicle right side is detected. • LDWS_Fail: Malfunction related to lane departure warning system (LDWS) is detected. • HBC_Fail: Malfunction related to HBC system is detected. • Camera_BLK: Dirt on camera is detected. • FOW_Warning: — • FOW_Fail: — • FSC_Fail: Forward sensing camera (FSC) malfunction is detected. • Camera_DRDT: Camera fogging is detected.	C, E (CAN)
HBC_H/L_CS	Hi_Request/ Low_Request/Invalid	• Hi_Request: HI beam switch signal received • Low_Request: LO beam switch signal received • Invalid: Error in HI/LO beam switch request signal	C, E (CAN)
IL_ST_HBC	Off/ Green_On/ Green_Flash/ Amber_On/ Amber_Flash	• Off: HBC system indicator light (green) and HBC system warning indicator light (amber) turned off • Green_On: HBC system indicator light (green) is illuminated. • Green_Flash: HBC system indicator light (green) is flashing. • Amber_On: HBC system warning light (amber) is illuminated. • Amber_Flash: HBC system warning light (amber) is flashing.	C, E (CAN)
IL_ST_LDWS	Off/ Green_On/ Green_Flash/ Amber_On/ Amber_Flash	• Off: LDWS indicator light (green) and LDWS warning light (amber) turned off • Green_On: LDWS indicator light (green) illuminated • Green_Flash: LDWS indicator light (green) is flashing. • Amber_On: LDWS warning light (amber) is illuminated. • Amber_Flash: LDWS warning light (amber) is flashing.	C, E (CAN)
LDWS_BUZZER	Off/On	• Off: LDWS warning alarm does not sound. • On: LDWS warning alarm sounds.	C, E (CAN)
LDWS_SW	Off/On	• Off: LDWS switch is off. • On: LDWS switch is on.	C, E (CAN)
RS_SOUND_CS	Off/Left/ Right	• Off: Rumble strip sound is not heard. • Left: Left side rumble strip sound heard. • Right: Right side rumble strip sound heard.	C, E (CAN)
VPWR_IG1	V	Displays forward sensing camera (FSC) power supply voltage	I (Power supply)

PID	Unit/ Operation	Data contents	Module control terminal
VSPD	KPH, MPH	Displays vehicle speed	C, E (CAN)