## SYMPTOM TROUBLESHOOTING [HEADLIGHT AUTO LEVELING SYSTEM]

id0903d0378800

| Troubleshooting item | Description |
|---|---|
| LED HEADLIGHT WARNING LIGHT ILLUMINATES CONTINUOUSLY<br>(See LED HEADLIGHT WARNING LIGHT ILLUMINATES CONTINUOUSLY [HEADLIGHT AUTO LEVELING SYSTEM].) | • Inspect the LED headlight warning light with the ignition switched ON (engine off or on). |
| THE HEADLIGHT AUTO LEVELING SYSTEM DOES NOT OPERATE IN RESPONSE TO VEHICLE POSTURE<br>(See THE HEADLIGHT AUTO LEVELING SYSTEM DOES NOT OPERATE IN RESPONSE TO VEHICLE POSTURE [HEADLIGHT AUTO LEVELING SYSTEM].) | • The headlight auto leveling system does operate in response to the number of occupants, cargo load in trunk, and the fuel level.<br>• One side of the headlight leveling actuator does not operate. |