LOW ENGINE COOLANT TEMPERATURE INDICATOR LIGHT/HIGH ENGINE COOLANT TEMPERATURE WARNING LIGHT ILLUMINATES OR FLASHES CONTINUOUSLY [INSTRUMENT CLUSTER]

id0903d5013300

Note
- If there is any vehicle malfunction complaint lodged by a customer, perform FOREWORD [INSTRUMENT CLUSTER] malfunction diagnosis according to the troubleshooting procedure. (See FOREWORD [INSTRUMENT CLUSTER].)

Possible cause
- ECT sensor malfunction
- Instrument cluster malfunction

Diagnostic Procedure

Step	Inspection	Action	
1	**PERFORM CAN MALFUNCTION DIAGNOSIS AND DTC INSPECTION** • Perform the CAN malfunction diagnosis according to the recommendation of FOREWORD [INSTRUMENT CLUSTER] malfunction diagnosis, and if there is no CAN malfunction, perform inspection for DTCs. (See DTC INSPECTION [INSTRUMENT CLUSTER].) • Is the DTC displayed?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [INSTRUMENT CLUSTER].)
		No	Go to the next step.
2	**VERIFY THE MALFUNCTION SYMPTOM** • Cool down the engine. • When the ignition is switched ON, does the engine coolant temperature warning light illuminate or flash?	Yes	Go to Step 4.
		No	Go to the next step.
3	**VERIFY ILLUMINATION OF LOW ENGINE COOLANT TEMPERATURE INDICATOR LIGHT** • Switch the ignition ON (engine on). • Monitor the PID ECT using the M-MDS. • Verify that the low engine coolant temperature indicator light illuminates when the ECT monitor value is **55 °C {131 °F} or more (SKYACTIV-G 1.3, SKYACTIV-G 1.5)** / **40 °C {104 °F} or more (SKYACTIV-D 1.5)**. • Does the low engine coolant temperature indicator light illuminate?	Yes	Go to the next step.
		No	The system is operating normally.
4	**INSPECT ECT SENSOR** • Inspect the ECT sensor. (See ENGINE COOLANT TEMPERATURE (ECT) SENSOR INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) (See ENGINE COOLANT TEMPERATURE (ECT) SENSOR INSPECTION [SKYACTIV-D 1.5].) • Is the ECT sensor normal?	Yes	Replace the instrument cluster. (See INSTRUMENT CLUSTER REMOVAL/ INSTALLATION.)
		No	Replace the ECT sensor. (See ENGINE COOLANT TEMPERATURE (ECT) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) (See ENGINE COOLANT TEMPERATURE (ECT) SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)