ACTIVE DRIVING DISPLAY IS NOT SET TO CORRECT POSITION [INSTRUMENT CLUSTER]

id0903d5025000

Note

- If there is any vehicle malfunction complaint lodged by a customer, perform FOREWORD [INSTRUMENT CLUSTER] malfunction diagnosis according to the troubleshooting procedure. (See FOREWORD [INSTRUMENT CLUSTER].)

Possible Cause

- Angle of the combiner is deviated (combiner open/close angle may deviate if foreign matter penetrates while it is opening/closing)
- Active driving display malfunction
- Instrument cluster malfunction

Diagnostic Procedure

Step	Inspection	Action	
1	**VERIFY THE COMBINER OPEN/CLOSE CONDITION** • Switch the ignition OFF. • Verify the combiner open/close condition. • Does the combiner partially open?	Yes	Perform the combiner angle initial setting. (See ACTIVE DRIVING DISPLAY INSPECTION.)
		No	Go to the next step.
2	**VISUALLY INSPECT ACTIVE DRIVING DISPLAY** • Switch the ignition ON (engine on). • Visually inspect the active driving display for damage, dust, or dirt. • Is there damage, foreign matter penetration, or dirt on the active driving display?	Yes	**If the active driving display is damaged:** • Replace the active driving display. (See ACTIVE DRIVING DISPLAY REMOVAL/ INSTALLATION.) **If there is foreign matter penetration or dirt on the active driving display:** • Remove foreign matter or dirt on the active driving display.
		No	Go to the next step.
3	**INSPECT ACTIVE DRIVING DISPLAY** • Inspect the active driving display. (See ACTIVE DRIVING DISPLAY INSPECTION.) • Is the active driving display normal?	Yes	Go to the next step.
		No	Replace the active driving display. (See ACTIVE DRIVING DISPLAY REMOVAL/ INSTALLATION.)
4	**VERIFY IF MALFUNCTION CAUSE IS CORRECTED** • Is the active driving display operating normally?	Yes	Troubleshooting completed (explain the contents of the servicing to the customer).
		No	Replace the instrument cluster. (See INSTRUMENT CLUSTER REMOVAL/ INSTALLATION.)

cardiagn.com