SYMPTOM TROUBLESHOOTING [INSTRUMENT CLUSTER]

id0903d5715100

Troubleshooting item
FUEL GAUGE READING IS NOT CORRECT (See FUEL GAUGE READING IS NOT CORRECT [INSTRUMENT CLUSTER].)
LOW ENGINE COOLANT TEMPERATURE INDICATOR LIGHT/HIGH ENGINE COOLANT TEMPERATURE WARNING LIGHT ILLUMINATES OR FLASHES CONTINUOUSLY (See LOW ENGINE COOLANT TEMPERATURE INDICATOR LIGHT/HIGH ENGINE COOLANT TEMPERATURE WARNING LIGHT ILLUMINATES OR FLASHES CONTINUOUSLY [INSTRUMENT CLUSTER].)
ACTIVE DRIVING DISPLAY DOES NOT DISPLAY (See ACTIVE DRIVING DISPLAY DOES NOT DISPLAY [INSTRUMENT CLUSTER].)
ACTIVE DRIVING DISPLAY DOES NOT OPERATE (See ACTIVE DRIVING DISPLAY DOES NOT OPERATE [INSTRUMENT CLUSTER].)
ACTIVE DRIVING DISPLAY DOES NOT DIM AUTOMATICALLY (See ACTIVE DRIVING DISPLAY DOES NOT DIM AUTOMATICALLY [INSTRUMENT CLUSTER].)
ACTIVE DRIVING DISPLAY IS NOT SET TO CORRECT POSITION (See ACTIVE DRIVING DISPLAY IS NOT SET TO CORRECT POSITION [INSTRUMENT CLUSTER].)

cardiagn.com