BLIND SPOT MONITORING (BSM) WARNING LIGHT FALSE FLASH [BLIND SPOT MONITORING (BSM)]

id0903d9055800

Note
- If there is any vehicle malfunction complaint lodged by a customer, first perform malfunction diagnosis according to the troubleshooting procedure. (See FOREWORD [BLIND SPOT MONITORING (BSM)].)

Description
- The blind spot monitoring (BSM) warningr light flashes while not under flashing conditions.

Possible malfunction

Note
- The detection performance of the blind spot monitoring (BSM) control module has limitations and the blind spot monitoring (BSM) system may not operate normally. For the detection performance limitations, refer to the [BLIND SPOT MONITORING (BSM) CONTROL MODULE] in the technical guide.

- The blind spot monitoring (BSM) control module falsely detects a vehicle outside of the detection area as inside it, or falsely detects a vehicle as entering the area.
  - — Deviation of the radar emission direction (emission outside of warning area, adjacent lane) of radar in the blind spot monitoring (BSM) control module.
    - Damage, deformity or looseness to blind spot monitoring (BSM) bracket or vehicle frame (including moderate impacts)
    - Incorrect installation of rear bumper, dirt on radar emitting/receiving area, application of stickers (including transparent types), repairs using putty application
  - — The blind spot monitoring (BSM) control module cannot receive echo-back correctly.
    - Blind spot monitoring (BSM) control module malfunction
    - Incorrect installation of rear bumper, dirt on radar emitting/receiving area, application of stickers (including transparent types), repairs using putty application
  - — Effect of non-genuine, after-market electronic device installation
- The blind spot monitoring (BSM) control module falsely detects a turn signal operation.
  - — Blind spot monitoring (BSM) control module (LH) malfunction
- Blind spot monitoring (BSM) warningr light flash circuit malfunction
  - — Blind spot monitoring (BSM) control module (RH) internal malfunction (malfunction in blind spot monitoring (BSM) warningr light flash circuit).
  - — Blind spot monitoring (BSM) control module (LH) malfunction (mistaken flash request output)

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY MALFUNCTION SYMPTOM** • Monitor the following blind spot monitoring (BSM) system PIDs using the M-MDS: (See PID/DATA MONITOR INSPECTION [BLIND SPOT MONITORING (BSM) SYSTEM].) — TURN_SW_R — TURN_SW_L • Does the monitoring value vary according to the turn signal switch operation?	Yes	Go to the next step.
		No	Perform the DTC inspection for the start stop unit, instrument cluster and the blind spot monitoring (BSM) control module. (See DTC INSPECTION [START STOP UNIT].) (See DTC INSPECTION [INSTRUMENT CLUSTER].) (See DTC INSPECTION [BLIND SPOT MONITORING (BSM) SYSTEM].)
2	**VERIFY REAR BUMPER CONDITION** • Inspect the rear bumper at the blind spot monitoring (BSM) control module installation areas for the following: — Installation condition — Application of stickers (including transparent types) — Excessive dirt — Repairs using putty • Is the rear bumper condition normal?	Yes	Go to the next step.
		No	Repair or replace the malfunctioning location, or replace the rear bumper. (See REAR BUMPER REMOVAL.) (See REAR BUMPER INSTALLATION.)

Step	Inspection		Action
3	**VERIFY INSTALLATION CONDITION OF BLIND SPOT MONITORING (BSM) CONTROL MODULE** • Remove the rear bumper. (See REAR BUMPER REMOVAL.) • Inspect the installation condition of the blind spot monitoring (BSM) control modules for the following. — Looseness — Damage or deformity to the bracket — Distortion at vehicle installation surface • Is the installation condition of the blind spot monitoring (BSM) control modules normal?	Yes	Go to the next step.
		No	Repair or replace the malfunctioning location.
4	**VERIFY IF MALFUNCTION CAUSE IS AFTER-MARKET ELECTRONIC DEVICE INSTALLATION** • Disconnect the non-genuine, after-market electronic device connectors. • Verify if the malfunction symptom recurs as stated by the customer. • Does the malfunction recur?	Yes	Go to the next step.
		No	Explain to the customer that the malfunction occurred due to the after-market electronic device installation.
5	**BLIND SPOT MONITORING (BSM) CONTROL MODULE INSPECTION** • Inspect the blind spot monitoring (BSM) control module on the side that is malfunctioning. (See BLIND SPOT MONITORING (BSM) CONTROL MODULE INSPECTION.) • Is the blind spot monitoring (BSM) control module normal?	Yes	A temporary malfunction in the radio wave emission from the blind spot monitoring (BSM) control module can be considered. If the same symptom recurs repeatedly, replace the blind spot monitoring (BSM) control module. (See BLIND SPOT MONITORING (BSM) CONTROL MODULE REMOVAL/INSTALLATION.)
		No	Replace the blind spot monitoring (BSM) control module. (See BLIND SPOT MONITORING (BSM) CONTROL MODULE REMOVAL/INSTALLATION.)