BLIND SPOT MONITORING (BSM) WARNING LIGHT DOES NOT TURN ON [BLIND SPOT MONITORING (BSM)]

id0903d9055900

Note
- If there is any vehicle malfunction complaint lodged by a customer, perform malfunction diagnosis first according to the troubleshooting procedure. (See FOREWORD [BLIND SPOT MONITORING (BSM)].)

Description
- The blind spot monitoring (BSM) warningr light does not turn on while under the illumination conditions.

Possible malfunction

Note
- The detection performance of the blind spot monitoring (BSM) control module has limitations and the blind spot monitoring (BSM) system may not operate normally. For the detection performance limitations, refer to the [BLIND SPOT MONITORING (BSM) CONTROL MODULE] in the technical guide.

- The blind spot monitoring (BSM) control module falsely detects a vehicle in the detection area as outside of it, or falsely detects a vehicle entering the area as not entering it.
  - — Deviation of the radar emission direction (emission outside of warning area, adjacent lane) of radar in the blind spot monitoring (BSM) control module.
    - Damage, deformity or looseness to blind spot monitoring (BSM) bracket or vehicle frame (including moderate impacts)
    - Incorrect installation of rear bumper, dirt on radar emitting/receiving area, application of stickers (including transparent types), repairs using putty application
  - — The blind spot monitoring (BSM) control module cannot receive echo-back correctly.
    - Blind spot monitoring (BSM) control module malfunction
    - Incorrect installation of rear bumper, dirt on radar emitting/receiving area, application of stickers (including transparent types), repairs using putty application
  - — Effect of non-genuine, after-market electronic device installation
- Blind spot monitoring (BSM) warningr light illumination-related malfunction
  - — Blind spot monitoring (BSM) warningr light
  - — Blind spot monitoring (BSM) control module (RH) malfunction (malfunction in blind spot monitoring (BSM) warningr light circuit).
  - — Blind spot monitoring (BSM) control module (LH) malfunction (illumination request not output).

Diagnostic Procedure

Warning
- **When performing a road test, always verify the safety of the surrounding area before performing the test.**
- **Do not perform a road test at a speed which exceeds the legal speed limit.**
- **To assure safety, perform a road test using two people when the vehicle is being driven. (One drives the vehicle and the other operates the M-MDS.)**

Step	Inspection		Action
1	**VERIFY MALFUNCTION SYMPTOM** • Turn the following blind spot monitoring system simulation function items on and off using the M-MDS simulation function. (See ACTIVE COMMAND MODES INSPECTION [BLIND SPOT MONITORING (BSM) SYSTEM].) — WRN_IND_R — WRN_IND_L • Does the blind spot monitoring (BSM) warningr light turn on/off?	Yes	Go to the next step.
		No	Go to Step 5.

Step	Inspection		Action
2	**VERIFY REAR BUMPER CONDITION** • Inspect the rear bumper at the blind spot monitoring (BSM) control module installation areas for the following: — Installation condition — Application of stickers (including transparent types) — Excessive dirt — Repairs using putty • Is the rear bumper condition normal?	Yes	Go to the next step.
		No	Repair or replace the malfunctioning location, or replace the rear bumper. (See REAR BUMPER REMOVAL.) (See REAR BUMPER INSTALLATION.)
3	**VERIFY INSTALLATION CONDITION OF BLIND SPOT MONITORING (BSM) CONTROL MODULE** • Remove the rear bumper. (See REAR BUMPER REMOVAL.) • Inspect the installation condition of the blind spot monitoring (BSM) control modules for the following. — Looseness — Damage or deformity to the bracket — Distortion at vehicle installation surface • Is the installation condition of the blind spot monitoring (BSM) control modules normal?	Yes	Go to the next step.
		No	Repair or replace the malfunctioning location.
4	**VERIFY IF MALFUNCTION CAUSE IS AFTER-MARKET ELECTRONIC DEVICE INSTALLATION** • Disconnect the non-genuine, after-market electronic device connectors. • Verify if the malfunction symptom recurs as stated by the customer. • Does the malfunction recur?	Yes	Go to Step 6.
		No	Explain to the customer that the malfunction occurred due to the after-market electronic device installation.
5	**BLIND SPOT MONITORING (BSM) WARNINGR LIGHT INSPECTION** • Inspect the illumination of the blind spot monitoring (BSM) warningr light. (See OUTER MIRROR GLASS INSPECTION.) • Is the blind spot monitoring (BSM) warningr light normal?	Yes	Go to the next step.
		No	Replace the outer mirror glass. (See OUTER MIRROR GLASS REMOVAL.) (See OUTER MIRROR GLASS INSTALLATION.)
6	**BLIND SPOT MONITORING (BSM) CONTROL MODULE INSPECTION** • Inspect the blind spot monitoring (BSM) control module on the side that is malfunctioning. (See BLIND SPOT MONITORING (BSM) CONTROL MODULE INSPECTION.) • Is the blind spot monitoring (BSM) control module normal?	Yes	A temporary malfunction in the radio wave emission from the blind spot monitoring (BSM) control module can be considered. If the same symptom recurs repeatedly, replace the blind spot monitoring (BSM) control module. (See BLIND SPOT MONITORING (BSM) CONTROL MODULE REMOVAL/INSTALLATION.)
		No	Replace the blind spot monitoring (BSM) control module. (See BLIND SPOT MONITORING (BSM) CONTROL MODULE REMOVAL/INSTALLATION.)