TROUBLESHOOTING INDEX [EMERGENCY STOP SIGNAL SYSTEM (ESS)]

id0903j7010500

Troubleshooting item	Description
ESS (EMERGENCY STOP SIGNAL SYSTEM) DOES NOT OPERATE (See ESS (EMERGENCY STOP SIGNAL SYSTEM) DOES NOT OPERATE [EMERGENCY STOP SIGNAL SYSTEM (ESS)].)	• The sudden deceleration hazard warning mode of the emergency signal system (ESS) does not operate. — The hazard warning lights do not flash even though the brake pedal is pressed and the vehicle decelerates suddenly*1 while driving at a vehicle speed of **60 km/h {37 mph} or more**. • The emergency stop hazard warning mode of the emergency signal system (ESS) does not operate. — Hazard warning lights stop flashing even though the brake pedal is depressed at a vehicle speed of **10 km/h {6.2 mph} or less** while the sudden deceleration hazard warning mode operates.
ESS (EMERGENCY STOP SIGNAL SYSTEM) OPERATES WHILE NOT UNDER OPERATION CONDITIONS (See ESS (EMERGENCY STOP SIGNAL SYSTEM) OPERATES WHILE NOT UNDER OPERATION CONDITIONS [EMERGENCY STOP SIGNAL SYSTEM (ESS)].)	• Hazard warning lights flash while driving. • Hazard warning lights flash even though deceleration is done without decelerating*1 rapidly.

*1 : Deceleration of vehicle speed at **30 km/h {19 mph} or more** for **1 s** while vehicle speed is **60—70 km/h {38—43 mph} or more**.