DEVIATION BETWEEN DRIVING DIAGNOSTIC SCORE AND DRIVE FEEL [INTELLIGENT DRIVE MASTER (i-DM)]

id0903k6017800

Description

- Frequency of the white lamp display is high even though the vehicle is driven on level straightaway.
- The driving diagnostic score according to a stage is not displayed.
- The driving diagnostic score is bad compared with another vehicle of the same model.

Possible Cause

- Connectivity master unit (CMU) malfunction
- Instrument cluster malfunction

White lamp deviation due to the pedal operation

- The PCM detects a malfunction and the vehicle driving condition is in fail-safe.
- Accelerator pedal position sensor signal error
  - — Accelerator pedal position sensor malfunction
  - — Accelerator pedal malfunction
  - — Wiring harness malfunction between accelerator pedal position sensor and PCM
- Vehicle speed signal error
  - — ABS wheel speed sensor malfunction (improper installation, malfunction)
  - — ABS wheel-speed sensor rotor loss
  - — Tire malfunction (pressure adjustment malfunction, irregular tire diameter)
- Engine malfunction (engine malfunction increases acceleration pedal depression)
  - — Abnormal acceleration
  - — Hesitation during acceleration

White lamp deviation due to the steering operation

- Steering angle (estimated absolute steering angle) signal error
  - — EPS control module malfunction
- Vehicle speed signal error
  - — ABS wheel speed sensor malfunction (improper installation, malfunction)
  - — ABS wheel-speed sensor rotor loss
  - — Tire malfunction (pressure adjustment malfunction, irregular tire diameter)

Diagnostic Procedure

Step	Inspection	Results	Action
1	**VERIFY DTCs FOR RELATED MODULES** • Using the M-MDS, verify DTCs for PCM, DSC HU/CM, EPS control module, instrument cluster and connectivity master unit (CMU). (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 1.3, SKYACTIV-G 1.5]) (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5]) (See DTC INSPECTION [DSC HU/CM]) (See DTC INSPECTION [EPS CONTROL MODULE]) (See DTC INSPECTION [INSTRUMENT CLUSTER]) (See DTC INSPECTION [CONNECTIVITY MASTER UNIT]) • Can DTCs be verified?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 1.3, SKYACTIV-G 1.5]) (SeeDTC TABLE [SKYACTIV-D 1.5]) (See DTC TABLE [DSC HU/CM]) (See DTC TABLE [EPS CONTROL MODULE]) (See DTC TABLE [INSTRUMENT CLUSTER]) (See DTC TABLE [CONNECTIVITY MASTER UNIT])
		No	• System is normal. If the vehicle is normal, refer to INTELLIGENT DRIVE MASTER (i-DM) for new vehicle instruction, and explain the contents of the driving operation determination and display to the customer to have them understand that there is no problem in the system. • Symptom troubleshooting is completed.