INTELLIGENT DRIVE MASTER LAMP NOT ILLUMINATED [INTELLIGENT DRIVE MASTER (i-DM)]

id0903k6019900

Description

- Intelligent drive master lamp is not illuminated.
- Acceleration/deceleration G, turning angle G rate of change (passenger oscillation speed), and range of change (extent of passenger oscillation) are not reflected by the white lamp.
- The white lamp does not operate even though acceleration/deceleration G, turning angle G rate of change (passenger oscillation speed), and range of change (extent of passenger oscillation) have changed.

Possible Cause

- Intelligent drive master screen setting
- Intelligent drive master related system malfunction
- Instrument cluster malfunction
- Connectivity master unit (CMU) malfunction

White lamp deviation due to the pedal operation

- The PCM detects a malfunction and the vehicle driving condition is in fail-safe.
- Accelerator pedal position sensor signal error
  - — Accelerator pedal position sensor malfunction
  - — Accelerator pedal malfunction
  - — Wiring harness malfunction between accelerator pedal position sensor and PCM

White lamp deviation due to the steering operation

- Steering angle (estimated absolute steering angle) signal error
  - — EPS control module malfunction

Diagnostic Procedure

Step	Inspection	Results	Action
1	**VERIFY INTELLIGENT DRIVE MASTER LAMP SETTING** • Verify the display/non-display of the intelligent drive master lamp display setting. (See INSTRUMENT CLUSTER PERSONALIZATION FEATURES SETTING PROCEDURE) • Is the intelligent drive master lamp switched between display and non-display?	Yes	• System is normal. Explain to the customer that the display setting of the intelligent drive master lamp is set to non-display. • Symptom troubleshooting is completed.
		No	Go to the next step.
2	**VERIFY DTCs FOR RELATED MODULES** • Using the M-MDS, verify DTCs for PCM, DSC HU/CM, EPS control module, instrument cluster and connectivity master unit (CMU). (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 1.3, SKYACTIV-G 1.5]) (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5]) (See DTC INSPECTION [DSC HU/CM]) (See DTC INSPECTION [EPS CONTROL MODULE]) (See DTC INSPECTION [INSTRUMENT CLUSTER]) (See DTC INSPECTION [CONNECTIVITY MASTER UNIT]) • Can DTCs be verified?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 1.3, SKYACTIV-G 1.5]) (See DTC TABLE [SKYACTIV-D 1.5]) (See DTC TABLE [DSC HU/CM]) (See DTC TABLE [EPS CONTROL MODULE]) (See DTC TABLE [INSTRUMENT CLUSTER]) (See DTC TABLE [CONNECTIVITY MASTER UNIT])
		No	• System is normal. If the vehicle is normal, refer to INTELLIGENT DRIVE MASTER (i-DM) for new vehicle instruction, and explain the contents of the driving operation determination and display to the customer to have them understand that there is no problem in the system. • Symptom troubleshooting is completed.