SYMPTOM TROUBLESHOOTING [ENTERTAINMENT SYSTEM [WITH CENTER DISPLAY]]

id0903I8059800

Troubleshooting item	Description
IMAGE NOT OUTPUT IN ALL MODES (See IMAGE NOT OUTPUT IN ALL MODES [ENTERTAINMENT SYSTEM [WITH CENTER DISPLAY]].)	• Image is not output in center display even if any mode is selected
DVD IMAGE NOT OUTPUT (See DVD IMAGE NOT OUTPUT [ENTERTAINMENT SYSTEM [WITH CENTER DISPLAY]].)	• Navigation images are output, however, DVD images are not • DVD sound is output, but not images
REAR MOUNT CAMERA IMAGE NOT CLEAR/NO IMAGE ON SCREEN (See REAR MOUNT CAMERA IMAGE NOT CLEAR/NO IMAGE ON SCREEN [ENTERTAINMENT SYSTEM [WITH CENTER DISPLAY]].)	• Navigation image is output, however, rear mount camera image is not output • Poor reception from rear mount camera
NO SOUND OUTPUT IN ALL MODES (See NO SOUND OUTPUT IN ALL MODES [ENTERTAINMENT SYSTEM [WITH CENTER DISPLAY]].)	• Sound is not output from speakers even if any mode is selected
NO SOUND OUTPUT IN MULTIPLE MODES (See NO SOUND OUTPUT IN MULTIPLE MODES [ENTERTAINMENT SYSTEM [WITH CENTER DISPLAY]].)	• Radio, CD, AUX audio is output, but no Bluetooth® audio, Internet radio, USB audio, and guidance voice
NO Bluetooth® AUDIO AND INTERNET RADIO SOUND (See NO Bluetooth® AUDIO AND INTERNET RADIO SOUND [ENTERTAINMENT SYSTEM [WITH CENTER DISPLAY]].)	• Radio, CD, AUX/USB audio, guidance audio is output, but no Bluetooth® audio, Internet radio audio
NO USB AUDIO SOUND OUTPUT (See NO USB AUDIO SOUND OUTPUT [ENTERTAINMENT SYSTEM [WITH CENTER DISPLAY]].)	• Radio, CD, AUX audio, Bluetooth® audio, Internet radio, and guidance audio is output, but not USB audio
NO NAVIGATION GUIDANCE VOICE OUTPUT (See NO NAVIGATION GUIDANCE VOICE OUTPUT [ENTERTAINMENT SYSTEM [WITH CENTER DISPLAY]].)	• Radio, CD, AUX/USB audio, Bluetooth® audio, and Internet radio audio is output, but no navigation guidance audio
NO VOICE RECOGNITION GUIDANCE VOICE OUTPUT (See NO VOICE RECOGNITION GUIDANCE VOICE OUTPUT [ENTERTAINMENT SYSTEM [WITH CENTER DISPLAY]].)	• Radio, CD, AUX/USB audio, Bluetooth® audio, and Internet radio audio is output, but not voice recognition guidance voice
NO DVD SOUND OUTPUT (See NO DVD SOUND OUTPUT [ENTERTAINMENT SYSTEM [WITH CENTER DISPLAY]].)	• Radio, CD, AUX audio, Bluetooth® audio, Internet radio, USB audio, and guidance audio is output, but not DVD audio • DVD images are output, but no audio
NO CD SOUND OUTPUT (See NO CD SOUND OUTPUT [ENTERTAINMENT SYSTEM [WITH CENTER DISPLAY]].)	• Radio, AUX audio, Bluetooth® audio, Internet radio, USB audio and guidance voice is output, but not CD sound
NO AUX AUDIO SOUND OUTPUT (See NO AUX AUDIO SOUND OUTPUT [ENTERTAINMENT SYSTEM [WITH CENTER DISPLAY]].)	• Radio, CD audio, Bluetooth® audio, Internet radio, and guidance audio is output, but not AUX audio
VOICE OPERATION NOT POSSIBLE (See VOICE OPERATION NOT POSSIBLE [ENTERTAINMENT SYSTEM [WITH CENTER DISPLAY]].)	• Voice operation of audio function, communication function, and navigation function is not possible
Bluetooth® PAIRING NOT POSSIBLE (See Bluetooth® PAIRING NOT POSSIBLE [ENTERTAINMENT SYSTEM [WITH CENTER DISPLAY]].)	• Bluetooth® enabled device cannot be paired to connectivity master unit (CMU)
AUTOMATIC Bluetooth® CONNECTION NOT POSSIBLE (See AUTOMATIC Bluetooth® CONNECTION NOT POSSIBLE [ENTERTAINMENT SYSTEM [WITH CENTER DISPLAY]].)	• Bluetooth® pairing setting is possible, however, automatic Bluetooth® connection is not possible
REAL TIME TRAFFIC FUNCTION INFORMATION NOT DISPLAYED (See REAL TIME TRAFFIC FUNCTION INFORMATION NOT DISPLAYED [ENTERTAINMENT SYSTEM [WITH CENTER DISPLAY]].)	• Information such as gas prices, weather, and nearest restaurant is not output in navigation mode
MAP IS NOT DISPLAYED (See MAP IS NOT DISPLAYED [ENTERTAINMENT SYSTEM [WITH CENTER DISPLAY]].)	• Navigation map is not displayed