## NO NAVIGATION GUIDANCE VOICE OUTPUT [ENTERTAINMENT SYSTEM [WITH CENTER DISPLAY]]

id0903l8060900

| | |
|---|---|
| **Description** | **NO NAVIGATION GUIDANCE VOICE OUTPUT** |
| | Radio, CD, AUX/USB audio, Bluetooth® audio, and Internet radio audio is output, but no navigation guidance audio |
| **Possible Causes** | • SD card malfunction<br>• Connector poor contact or terminal damage<br>• Auxiliary jack/USB port/SD card slot hub malfunction<br>• Global positioning system (GPS) antenna malfunction<br>• CMU malfunction |

### Diagnostic Procedure

| Step | Inspection | | Action |
|---|---|---|---|
| 1 | **VERIFY VOLUME SETTING**<br>• Switch the ignition to ACC or ON (engine off or on).<br>• Select the navigation mode by operating the commander switch or the center display.<br>• Operate the navigation guidance audio by operating the commander switch or the steering switch.<br>• Is navigation guidance audio output according to the operation? | Yes | System is normal. |
| | | No | Go to the next step. |
| 2 | **VISUALLY INSPECT SD CARD**<br>• Switch the ignition off.<br>• Visually inspect the SD card for looseness or damage.<br>• Is the SD card normal? | Yes | Go to the next step. |
| | | No | System is normal. (explain to the customer that there is a malfunction in SD card.) |
| 3 | **INSPECT GPS ANTENNA CONNECTOR**<br>• Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION.)<br>• Disconnect the GPS antenna connector.<br>• Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection.<br>• Is the connector normal? | Yes | Go to the next step. |
| | | No | Repair or replace the connector, then go to Step 6. |
| 4 | **VERIFY IF MALFUNCTION CAUSE IS AUXILIARY JACK/USB PORT/SD CARD SLOT HUB**<br>• Replace the auxiliary jack/USB port/SD card slot hub. (See AUXILIARY JACK/USB PORT/SD CARD SLOT HUB REMOVAL/INSTALLATION.)<br>• Connect all the connectors.<br>• Reconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION.)<br>• Insert the SD card when the malfunction occurred.<br>• Switch the ignition to ACC or ON (engine off or on).<br>• Select navigation by operating the center display or the commander switch.<br>• Set to an optional destination and operate the navigation function.<br>• Is navigation guidance audio output according to the operation? | Yes | Troubleshooting completed. (Explain the contents of the servicing to the customer.) |
| | | No | Go to the next step. |

| Step | Inspection | | Action |
|---|---|---|---|
| 5 | **VERIFY IF MALFUNCTION CAUSE IS GPS ANTENNA**<br>• Switch the ignition off.<br>• Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION.)<br>• Replace the GPS antenna. (See GLOBAL POSITIONING SYSTEM (GPS) ANTENNA REMOVAL/INSTALLATION.)<br>• Connect all the connectors.<br>• Reconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION.)<br>• Insert the SD card when the malfunction occurred.<br>• Switch the ignition to ACC or ON (engine off or on).<br>• Select navigation by operating the center display or the commander switch.<br>• Set to an optional destination and operate the navigation function.<br>• Is navigation guidance audio output according to the operation? | Yes | Troubleshooting completed. (Explain the contents of the servicing to the customer.) |
| | | No | Replace the CMU, then go to the next step. (See CONNECTIVITY MASTER UNIT (CMU) REMOVAL/INSTALLATION.) |
| 6 | **VERIFY IF MALFUNCTION CAUSE IS CORRECTED**<br>• Switch the ignition off.<br>• Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION.)<br>• Connect all the connectors.<br>• Reconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION.)<br>• Insert the SD card when the malfunction occurred.<br>• Switch the ignition to ACC or ON (engine off or on).<br>• Select navigation by operating the center display or the commander switch.<br>• Set to an optional destination and operate the navigation function.<br>• Is navigation guidance audio output according to the operation? | Yes | Troubleshooting completed. (Explain the contents of the servicing to the customer.) |
| | | No | Verify the malfunction symptom in the symptom troubleshooting chart and perform the other applicable malfunction diagnosis. (See SYMPTOM TROUBLESHOOTING [ENTERTAINMENT SYSTEM [WITH CENTER DISPLAY]].) |