SYMPTOM TROUBLESHOOTING [ENTERTAINMENT SYSTEM [WITHOUT CENTER DISPLAY]]

id0903I9059800

Troubleshooting item	Description
NO SOUND OUTPUT IN ALL MODES (See NO SOUND OUTPUT IN ALL MODES [ENTERTAINMENT SYSTEM [WITHOUT CENTER DISPLAY]].)	• Sound is not output from speakers even if any mode is selected
NO USB AUDIO SOUND OUTPUT (See NO USB AUDIO SOUND OUTPUT [ENTERTAINMENT SYSTEM [WITHOUT CENTER DISPLAY]].)	• Radio, CD, AUX audio, Bluetooth® audio is output, but no USB sound
NO CD SOUND OUTPUT (See NO CD SOUND OUTPUT [ENTERTAINMENT SYSTEM [WITHOUT CENTER DISPLAY]].)	• Radio, AUX audio, Bluetooth® audio, and USB audio is output, but no CD sound
NO AUX AUDIO SOUND OUTPUT (See NO AUX AUDIO SOUND OUTPUT [ENTERTAINMENT SYSTEM [WITHOUT CENTER DISPLAY]].)	• Radio, CD, USB audio, Bluetooth® audio is produced, but no AUX audio
AUDIO UNIT DISPLAY NOT DISPLAYED (See AUDIO UNIT DISPLAY NOT DISPLAYED [ENTERTAINMENT SYSTEM [WITHOUT CENTER DISPLAY]].)	• Does not display even with the audio unit power turned on