POWER OUTER MIRROR SWITCH REMOVAL/INSTALLATION

id091200014000

Note
- The power outer mirror switch is integrated with the power window main switch.

1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/ CONNECTION.)
2. Remove the power window main switch. (See POWER WINDOW MAIN SWITCH REMOVAL/ INSTALLATION.)
3. Install in the reverse order of removal.