SECURITY AND LOCKS PERSONALIZATION

id091400111100

Caution

- **The personalization feature may not be set correctly if [Not equipped] is selected in the setting displayed on the Mazda Modular Diagnostic System (M-MDS). Do not select [Not equipped] in the setting displayed on the Mazda modular diagnostic system (M-MDS).**

- A personalization feature has been adopted which switches each function between operation/non-operation.
- The settings of the following functions, and warning and guidance functions for the system can be turned ON/OFF optionally.
- The Mazda Modular Diagnostic System (M-MDS) is required to perform the setting. Refer to the SECURITY AND LOCKS PERSONALIZATION FEATURES SETTING PROCEDURE in the workshop manual for the detailed setting procedure.

Advanced Keyless Entry System
Mazda modular diagnostic system (M-MDS) used

Mazda modular diagnostic system (M-MDS) display	Function	Initial setting	Setting contents	Control unit
Advanced keyless function.*1	Advanced keyless entry system and push button start system functions can be disabled (disable).	Enable	Enable/Disable	Start stop unit
Walk Away Lock.	The out-of-area (reception area) type auto lock function can be set.	OFF	OFF/ON	Start stop unit
Auto Relock Time.	The operation start time of the auto re-lock function can be changed.	30 seconds.	30 seconds./60 seconds./90 seconds.	Start stop unit
Keyless Lock Beep Volume.*2	The keyless beeper volume can be adjusted.	Medium	Off/Low/ Medium/High	Start stop unit

*1 : Because the push button start system function has been disabled, start the engine while touching the center of the push button start with the upper part of the remote transmitter.
*2 : Settings can be changed by operation of the remote transmitter button. Refer to the SECURITY AND LOCKS PERSONALIZATION FEATURES SETTING PROCEDURE in the workshop manual for the detailed setting procedure.

Using center display

Display of center display	Function	Initial setting	Setting contents	Control unit
Keyless Lock Beep Volume	The keyless beeper volume can be adjusted.	Medium	Off / Low / Medium / High	Start stop unit
Door Relock Time	The operation start time of the auto re-lock function can be changed.	30 seconds	30 seconds / 60 seconds / 90 seconds	Start stop unit
Walk Away Lock	The out-of-area (reception area) type auto lock function can be set.	OFF	OFF / ON	Start stop unit
Reset	The setting content for the advanced keyless entry system can be returned to the initial value.	NO	YES / NO	• Start stop unit • BCM

Keyless Entry System
Mazda modular diagnostic system (M-MDS) used

Mazda modular diagnostic System (M-MDS) display	Function	Initial setting	Setting contents	Control unit
Advanced keyless function.*1	The advanced keyless entry system and push button start system functions can be disabled (unusable).	Enable	Enable/Disable	Start stop unit

Mazda modular diagnostic System (M-MDS) display	Function	Initial setting	Setting contents	Control unit
Auto Relock Time.	The operation start time of the auto re-lock function can be changed.	30 seconds.	30 seconds./60 seconds./90 seconds.	Start stop unit

*1 : Because the push button start system function has been disabled, start the engine while touching the center of the push button start with the upper part of the remote transmitter.

Using center display

Display of center display	Function	Initial setting	Setting contents	Control unit
Door Relock Time	The operation start time of the auto re-lock function can be changed.	30 seconds	30 seconds / 60 seconds / 90 seconds	Start stop unit
Reset	The setting content for the keyless entry system can be returned to the initial value.	NO	YES / NO	• Start stop unit • BCM

Power Door Lock System
Mazda modular diagnostic system (M-MDS) used

Mazda Modular Diagnostic System (M-MDS) display	Function	Initial setting	Setting contents	Control unit
Auto Door Lock Mode*1	Auto door lock function can be changed.	Lock: Driving, Unlock: IGN Off.	Off/Lock: When Driving, Unlock: In Park./Lock When Driving./ Lock: Driving, Unlock: IGN Off./Lock When Shifting Out Of P./Lock: Shift From P, Unlock: In P.	BCM

*1 : Settings can be changed by operation of the door lock switch. Refer to the CONTROL SYSTEM PERSONALIZATION FEATURES SETTING PROCEDURE in the workshop manual for the detailed setting procedure.

Using center display

Display of center display	Function	Initial setting	Setting contents	Control unit
Auto Door Lock Mode	Auto door lock function can be changed.	Lock: When Driving, Unlock: IGN Off	Off / Lock: When Driving, Unlock: In Park / Lock: When Driving / Lock: When Driving, Unlock: IGN Off / Lock: Shifting from Park / Lock: Shifting from Park, Unlock: In Park	BCM
Reset	Returns the setting content of the door lock system to the initial setting.	NO	YES / NO	• Start stop unit • BCM