TRUNK LID LATCH AND RELEASE ACTUATOR INSPECTION

id091400513400

- The following actuator and switch are integrated with the trunk lid latch and release actuator.
- From the actuator/switch name and operation in the following table, select the actuator or switch to be inspected, and perform the inspection following the inspection procedure described in the reference.

Actuator/Switch name	Operation	Reference
Trunk lid release actuator	Electrically unlatches the trunk lid based on the signal from the BCM.	(See TRUNK LID RELEASE ACTUATOR INSPECTION.)
Trunk lid latch switch	Turns on/off in conjunction with the latch lever rotation so that the trunk lid open/closed condition is detected.	(See TRUNK LID LATCH SWITCH INSPECTION.)