8. Disconnect the connector from the theft-deterrent siren.
9. Remove the short-cord from the theft-deterrent siren.