LIGHTING SYSTEM PERSONALIZATION

id091800013300

Caution

- **The personalization feature may not be set correctly if [Not equipped] is selected in the setting displayed on the Mazda Modular Diagnostic System (M-MDS). Do not select [Not equipped] in the setting displayed on the Mazda Modular Diagnostic System (M-MDS).**

Note

- Settings of some personalization features displayed on the Mazda Modular Diagnostic System (M-MDS) cannot be changed depending on the vehicle specification.

- A personalization feature has been adopted with which settings for each function can be changed.
- The setting for each function can be switched using the Mazda Modular Diagnostic System (M-MDS) or the center display (with center display). Refer to the [LIGHTING SYSTEM PERSONALIZATION FEATURES SETTING PROCEDURE] in the workshop manual for the detailed setting procedure.

Auto Light System

Mazda Modular Diagnostic System (M-MDS)

Mazda Modular Diagnostic System (M-MDS) display	Function	Initial setting	Setting contents	Control module
Auto Headlight On	Auto light sensitivity can be changed.	Standard (All Others)	Extra Low (Except Japan)/Low (All Others)/Standard (All Others)/High (Except Japan)/Extra High (Except Japan)	BCM

Center display

Display of center display	Function	Initial setting	Setting contents	Control module
Auto Headlight On	Auto light sensitivity can be changed.	Medium	Light / Medium Light / Medium / Medium Dark / Dark	BCM

Note

- If the mode is set to [Extra High (Except Japan)] and [High (Except Japan)], the illuminance level for turning on the headlight LO, TNS, and panel light increases. Therefore, each light turns on when the ambient light is brighter than when the level is set to [Standard (All Others)]. In addition, if the mode is set to [Extra Low (Except Japan)] or [Low (All Others)], the illuminance level for turning on the headlight LO, TNS, and panel light decreases. Therefore, each light turns on when the ambient light is darker than when the level is set to [Standard (All Others)].
- The personalization feature may not be set correctly if [Japan Only], such as [Extra High (Japan Only)], is selected. Do not select [Japan Only].

- The auto light sensitivity setting turns on/off the headlight LO, TNS, and panel light according to the following illumination levels.

Note

- The following illumination levels are a reference. The illumination levels vary depending on the surrounding conditions (weather, reflection off buildings).

Setting contents	Lights on operation		Lights off operation	
	Panel light On	Panel light On	Panel light On	Panel light Off
	TNS Off	TNS On	TNS Off	TNS Off
	Headlight LO Off	Headlight LO On	Headlight LO Off	Headlight LO Off
Extra High	1,000 lux	4,000 lux	8,000 lux	2,000 lux
High	850 lux	3,000 lux	6,000 lux	1,700 lux
Standard	700 lux	2,000 lux	4,000 lux	1,400 lux
Low	550 lux	1,000 lux	2,000 lux	1,100 lux
Extra Low	400 lux	500 lux	1,000 lux	800 lux

Turn light system

Mazda Modular Diagnostic System (M-MDS)

Mazda Modular Diagnostic System (M-MDS) display	Function	Initial setting	Setting contents	Control module
Three-Flash Turn Signal	The operation of the three-flash turn signal function can be disabled.	Off (except for Israel)/ On (for Israel)	Off/On	BCM

Center display

Display of center display	Function	Initial setting	Setting contents	Control module
3-Flash Turn Signal	The turn light system can be switched between operable and inoperable.	On	On / Off	BCM

High Beam Control (HBC) System

Mazda Modular Diagnostic System (M-MDS)

Mazda Modular Diagnostic System (M-MDS) display	Function	Initial setting	Setting contents	Control module
High Beam Control.	The high beam control (HBC) system can be switched between operable and inoperable.	ON	OFF/ON	Forward sensing camera (FSC)

Center display

Display of center display	Function	Initial setting	Setting contents	Control module
High Beam Control	The high beam control (HBC) system can be switched between operable and inoperable.	On	On / Off	Forward sensing camera (FSC)

Coming Home Light System

Mazda Modular Diagnostic System (M-MDS)

Mazda Modular Diagnostic System (M-MDS) display	Function	Initial setting	Setting contents	Control module
Coming Home Light operation time	The coming home light system operation time can be switched.	30 seconds.	0 seconds./30 seconds./60 seconds./ 90 seconds./120 seconds.	BCM

Center display

Display of center display	Function	Initial setting	Setting contents	Control module
Coming Home Lights Timer	The coming home light system operation time can be switched.	30 seconds	Off / 30 seconds / 60 seconds / 90 seconds / 120 seconds	BCM

Leaving Home Light System

Mazda Modular Diagnostic System (M-MDS)

Mazda Modular Diagnostic System (M-MDS) display	Function	Initial setting	Setting contents	Control module
Leaving Home Light system	The leaving home light system can be switched between operable and inoperable.	Off (except European (L.H.D. U.K.) specs.)/ On (European (L.H.D. U.K.) specs.)	Off/On	BCM

Center display

Display of center display	Function	Initial setting	Setting contents	Control module
Leaving Home Lights	The leaving home light system can be switched between operable and inoperable.	Off (except European (L.H.D. U.K.) specs.)/ On (European (L.H.D. U.K.) specs.)	On / Off	BCM

Dimmer switch is operated

Function	Initial setting	Setting contents	Control module
The leaving home light system can be switched between operable and inoperable.	Inoperable (except European (L.H.D. U.K.) specs.)/ Operable (European (L.H.D. U.K.) specs.)	Operable/Inoperable	BCM

Interior Light Control System

Mazda Modular Diagnostic System (M-MDS)

Mazda Modular Diagnostic System (M-MDS) display	Function	Initial setting	Setting contents	Control module
Interior Lighting Timeout-Door Open	• The map light illumination time after a door is opened can be changed. • The trunk compartment light (4SD)/cargo compartment light (5HB) illumination time after the trunk lid (4SD)/liftgate (5HB) is opened can be changed.	30 minutes.	30 minutes./60 minutes./10 minutes.	BCM
Interior Lighting Timeout-Door Closed	The map light illumination time after all doors are closed can be changed.	15 seconds.	15 seconds./7.5 seconds./30 seconds./ 60 seconds.	BCM

Center display

Display of center display	Function	Initial setting	Setting contents	Control module
Interior Light Timeout - Doors Open	• The front/rear map light illumination time after any door is opened can be changed. • The trunk compartment light (4SD)/cargo compartment light (5HB) illumination time after the trunk lid (4SD)/ liftgate (5HB) is opened can be changed.	30 minutes	60 minutes / 30 minutes / 10 minutes	BCM
Interior Light Timeout - Doors Closed	The front/rear map light illumination time after all the doors are closed can be changed.	15 seconds	60 seconds / 30 seconds / 15 seconds / 7.5 seconds	BCM

Running Light System

Function	Initial setting	Setting contents	Control module
The running light system function can be set.	On (Running light illumination)	Off (Running light non-illumination)/On (Running light illumination)	BCM