HEADLIGHT LEVELING SWITCH REMOVAL/INSTALLATION

id091800803600

Note
- The headlight leveling switch is integrated with the cluster switch.
- Refer to CLUSTER SWITCH REMOVAL/INSTALLATION for the headlight leveling switch removal/installation. (See CLUSTER SWITCH REMOVAL/INSTALLATION.)