## AUTO LIGHT SENSOR REMOVAL/INSTALLATION

id091800807200

**Note**
- The auto light sensor is integrated with the rain sensor as a single unit.
- When replacing the auto light sensor, refer to RAIN SENSOR REMOVAL/INSTALLATION. (See RAIN SENSOR REMOVAL/INSTALLATION.)