WINDSHIELD WIPER ARM AND BLADE REMOVAL/INSTALLATION

id091900903100

Windshield Wiper Arm

1. Open the bonnet.
2. Carefully pull the cap up in the direction of arrow (1) shown in the figure while slightly shaking it, and detach the cap from the windshield wiper arm.



6. Raise the windshield wiper arm as shown in the figure.

Caution

- **If the windshield wiper arm end is placed directly on the windshield after removing**