CENTER DISPLAY PERSONALIZATION FEATURES SETTING PROCEDURE

id092000013100

Smart City Brake Support (SCBS)

1. Switch the ignition ON (engine off or on).
2. Select [Settings] on the center display.
3. Select [Safety] on the center display.
4. Select an item name, and then select option.

Display of center display	Function	Initial setting	Settings	Control module
Smart City Brake Support	The operation of smart city brake support (SCBS) can be turned off.	On	On / Off	Laser sensor

Door Locks Systems

1. Switch the ignition ON (engine off or on).
2. Select [Settings] on the center display.
3. Select [Vehicle] on the center display.
4. Select [Door Lock] on the center display.
5. Select an item name, and then select option.

Power Door Lock System

Display of center display	Function	Initial setting	Settings	Control module
Auto Door Lock Mode	Auto door lock function can be changed.	Lock: When Driving, Unlock: IGN Off	Off / Lock: When Driving, Unlock: In Park / Lock: When Driving / Lock: When Driving, Unlock: IGN Off / Lock: Shifting from Park / Lock: Shifting from Park, Unlock: In Park	BCM
Reset	Returns the setting content of the door lock system to the initial setting.	No	No / Yes	• Start stop unit • BCM

Advanced keyless entry system

Display of center display	Function	Initial setting	Settings	Control module
Keyless Lock Beep Volume	The keyless beeper volume can be adjusted.	Medium	High / Medium / Low / Off	Start stop unit
Auto Relock Time	The operation start time of the auto re-lock function can be changed.	30 seconds	30 seconds / 60 seconds / 90 seconds	Start stop unit
Walk Away Lock	The out-of-area (reception area) type auto lock function can be set.	Off	Off / On	Start stop unit
Reset	Returns the setting content of the door lock system to the initial setting.	No	No / Yes	• Start stop unit • BCM

Keyless entry system

Display of center display	Function	Initial setting	Settings	Control module
Auto Relock Time	The operation start time of the auto re-lock function can be changed.	30 seconds	30 seconds / 60 seconds / 90 seconds	Start stop unit

Display of center display	Function	Initial setting	Settings	Control module
Reset	Returns the setting content of the door lock system to the initial setting.	No	No / Yes	• Start stop unit • BCM

Lighting Systems

1. Switch the ignition ON (engine off or on).
2. Select [Settings] on the center display.
3. Select [Vehicle] on the center display.
4. Select [Lighting] on the center display.
5. Select an item name, and then select option.

Room light control system

Display of center display	Function	Initial setting	Settings	Control module
Interior Light Timeout - Doors Open	• The front/rear map light illumination time after any door is opened can be changed. • The trunk compartment light (4SD)/cargo compartment light (5HB) illumination time after the trunk lid (4SD)/liftgate (5HB) is opened can be changed.	30 minutes	60 minutes / 30 minutes / 10 minutes	BCM
Interior Light Timeout - Doors Closed	The front/rear map light illumination time after all the doors are closed can be changed.	15 seconds	60 seconds / 30 seconds / 15 seconds / 7.5 seconds	BCM
Reset	Returns the setting content of the lighting system to the initial setting.	No	No / Yes	• BCM • FSC • Instrument cluster

High beam control (HBC) system

Display of center display	Function	Initial setting	Settings	Control module
High Beam Control	The high beam control (HBC) system can be switched between operable and inoperable.	On	On / Off	FSC
Reset	Returns the setting content of the lighting system to the initial setting.	No	No / Yes	• BCM • FSC • Instrument cluster

Lights-on reminder warning alarm

Display of center display	Function	Initial setting	Settings	Control module
Light On Reminder Vol	The volume for the lights-on reminder warning alarm can be changed.	High	High / Low / Off	Instrument cluster
Reset	Returns the setting content of the lighting system to the initial setting.	No	No / Yes	• BCM • FSC • Instrument cluster

Running light system (australian specs.)

Display of center display	Function	Initial setting	Settings	Control module
Daytime Running Lights	The running light system function can be set.	On	On / Off	BCM

Display of center display	Function	Initial setting	Settings	Control module
Reset	Returns the setting content of the lighting system to the initial setting.	No	No / Yes	• BCM • FSC • Instrument cluster

Auto light system

Display of center display	Function	Initial setting	Settings	Control module
Auto Headlight On	Auto light sensor sensitivity can be changed.	Medium	Light / Medium Light / Medium / Medium Dark / Dark	BCM
Reset	Returns the setting content of the lighting system to the initial setting.	No	No / Yes	• BCM • FSC • Instrument cluster

Coming home light system

Display of center display	Function	Initial setting	Settings	Control module
Coming Home Lights Timer	The coming home light system operation time can be switched.	30 seconds	Off / 30 seconds / 60 seconds / 90 seconds / 120 seconds	BCM
Reset	Returns the setting content of the lighting system to the initial setting.	No	No / Yes	• BCM • FSC • Instrument cluster

Leaving home light system

Display of center display	Function	Initial setting	Settings	Control module
Leaving Home Lights	The leaving home light system can be switched between operable and inoperable.	Off (except European (L.H.D. U.K.) specs.)/On (European (L.H.D. U.K.) specs.)	On / Off	BCM
Reset	Returns the setting content of the lighting system to the initial setting.	No	No / Yes	• BCM • FSC • Instrument cluster

Auto Wiper System

1. Switch the ignition ON (engine off or on).
2. Select [Settings] on the center display.
3. Select [Vehicle] on the center display.
4. Select an item name, and then select option.

Display of center display	Function	Initial setting	Settings	Control module
Rain Sensing Wiper	The auto wiper function can be disabled.	On	On / Off*1	BCM

*1 : If the function is set to “Off”, the wipers will operate intermittently with the wiper switch in AUTO position.

Blind Spot Monitoring (BSM) System

1. Switch the ignition ON (engine off or on).
2. Select [Settings] on the center display.
3. Select [Safety] on the center display.
4. Select an item name, and then select option.

Display of center display	Function	Initial setting	Settings	Control module
Blind Spot Monitor Volume	The volume of the blind spot monitoring (BSM) warning alarm can be changed.	High	High / Low / Off	Instrument cluster

Lane Departure Warning System (LDWS)

1. Switch the ignition ON (engine off or on).
2. Select [Settings] on the center display.
3. Select [Safety] on the center display.
4. Select [Lane Departure Warning System] on the center display.
5. Select an item name, and then select option.

Display of center display	Function	Initial setting	Settings	Control module
Timing	The distance between the warning-trigger lines for the Lane Departure Warning System (LDWS) and vehicle lanes can be changed.	Before Line	At Line / Before Line	FSC
Warning	The warning operation sensitivity of the lane departure warning system (LDWS) can be changed.	Low	High / Low	FSC
Sound	The type of the LDWS warning alarm can be changed.	Rumble	Beep / Rumble	Instrument cluster
Beep Volume	The volume of the LDWS warning alarm (Beep) can be changed.	Low	High / Low	Instrument cluster
Rumble Strip Volume	The volume of the LDWS warning alarm (Rumble) can be changed.	Low	High / Mid / Low	Instrument cluster
Reset	Returns the setting content of the lane departure warning system to the initial setting.	No	No / Yes	• FSC • Instrument cluster

Turn Light System

1. Switch the ignition ON (engine off or on).
2. Select [Settings] on the center display.
3. Select [Vehicle] on the center display.
4. Select [Turn] on the center display.
5. Select an item name, and then select option.

Display of center display	Function	Initial setting	Settings	Control module
3-Flash Turn Signal	The turn light system can be switched between operable and inoperable.	On	On / Off	BCM
Turn Signal Volume	The volume of the turn and hazard indicator alarm can be changed.	High	High / Low	Instrument cluster
Reset	Returns the setting content of the turn light system to the initial setting.	No	No / Yes	• BCM • Instrument cluster

Language

1. Switch the ignition ON (engine off or on).
2. Select [Settings] on the center display.
3. Select [System] on the center display.
4. Select an item name, and then select option.

Display of center display	Function	Initial setting	Settings	Control module
Language	The display language can be changed.	English	English/French/German/Italian/ Spanish/Russian/Portuguese/ Dutch/Swedish/Danish/ Norwegian/Finnish/Czech/ Slovakian/Hungarian/Turkish/ Polish/Estonian/Latvian/ Lithuanian/Greek/Croatian/ Bulgarian/Romanian/Serbian/ Hebrew	Connectivity master unit (CMU)

Distance
1. Switch the ignition ON (engine off or on).
2. Select [Settings] on the center display.
3. Select [System] on the center display.
4. Select an item name, and then select option.

Display of center display	Function	Initial setting	Settings	Control module
Distance	The distance unit can be changed.	Miles or km*1	Miles / km	Instrument cluster

*1 : The initial value differs depending on the market.

Temperature (digital speedometer type, analog speedometer type (Type A, B) instrument cluster only)
1. Switch the ignition ON (engine off or on).
2. Select [Settings] on the center display.
3. Select [System] on the center display.
4. Select an item name, and then select option.

Display of center display	Function	Initial setting	Settings	Control module
Temp*1	The temperature unit can be changed.	°F or °C*2	°F / °C	Instrument cluster

*1 : When the ambient temperature display is switched, the set A/C cabin temperature display is also changed.
*2 : The initial value differs depending on the market.

Active driving display
1. Switch the ignition ON (engine off or on).
2. Select [Settings] on the center display.
3. Select [AD-Disp] on the center display.
4. Select an item name, and then select option.

Display of center display	Function	Initial setting	Settings	Control module
Navigation	The turn-by-turn display can be switched between display/non-display.	On	On / Off	Connectivity master unit (CMU)

Fuel economy monitor
1. Switch the ignition ON (engine off or on).
2. Select [Application] on the center display.
3. Select [Fuel economy monitor] on the center display.
4. Press the setting button on the menu screen.
5. Select an item name, and then select option.

Display of center display	Function	Initial setting	Settings	Control module
Show Screen at Ignition Off	The ending screen of the fuel monitor can be switched between display/non-display.	On	On / Off	Connectivity master unit (CMU)

Display of center display	Function	Initial setting	Settings	Control module
Sync Average and Trip A	The function which synchronizes the reset of the fuel reset and trip meters can be switched between on/off.	On	On / Off	Connectivity master unit (CMU)