CENTER ROOF ANTENNA INSPECTION

id092000801700

Note

- The center roof antenna is integrated with the antenna amplifier.

Antenna amplifier inspection

1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/ CONNECTION.)
2. Remove the following parts:
   (1) Front scuff plate (See FRONT

11. Measure the voltage at center roof antenna connector terminal B.