INSTRUMENTATION/DRIVER INFO. PERSONALIZATION

id092200018400

Caution

- **The personalization feature may not be set correctly if [Not equipped] is selected in the setting displayed on the Mazda modular diagnostic system (M-MDS). Do not select [Not equipped] in the setting displayed on the Mazda modular diagnostic system (M-MDS).**

Note

- Settings of some personalization features displayed on the Mazda Modular Diagnostic System (M-MDS) cannot be changed depending on the vehicle specification.

- A personalization feature has been adopted which enables the instrument cluster settings to be changed.
- The setting for each function can be switched using the Mazda Modular Diagnostic System (M-MDS) or the center display (with center display). Refer to the [INSTRUMENT CLUSTER PERSONALIZATION FEATURES SETTING PROCEDURE] in the workshop manual for the detailed setting procedure.

Turn and Hazard Indicator Alarm
Mazda Modular Diagnostic System (M-MDS)

Mazda Modular Diagnostic System (M-MDS) display	Function	Initial setting	Setting contents	Control unit
Turn Signal Volume.	The volume of the turn and hazard indicator alarm can be changed.	High	Low/High	Instrument cluster

Center display

Display of center display	Function	Initial setting	Setting contents	Control unit
Turn Signal Volume	The volume of the turn and hazard indicator alarm can be changed.	High	High / Low	Instrument cluster

Lights-on Reminder Warning Alarm
Mazda Modular Diagnostic System (M-MDS)

Mazda Modular Diagnostic System (M-MDS) display	Function	Initial setting	Setting contents	Control unit
Lights On Reminder Volume.	The volume of the lights-on reminder warning alarm can be changed.	High	OFF/Low/High	Instrument cluster

Center display

Display of center display	Function	Initial setting	Setting contents	Control unit
Light On Reminder Vol	The volume for the lights-on reminder warning alarm can be changed.	High	High / Low / Off	Instrument cluster

Blind Spot Monitoring (BSM) System
Mazda Modular Diagnostic System (M-MDS)

Mazda Modular Diagnostic System (M-MDS) display	Function	Initial setting	Setting contents	Control unit
BSM Volume.	The volume of the blind spot monitoring (BSM) warning buzzer can be changed.	High	OFF/Low/High	Instrument cluster

Center display

Display of center display	Function	Initial setting	Setting contents	Control unit
Blind Spot MonitorVolume	The volume of the blind spot monitoring (BSM) warning buzzer can be changed.	High	High / Low / Off	Instrument cluster

Lane Departure Warning System (LDWS)
Mazda Modular Diagnostic System (M-MDS)

Mazda Modular Diagnostic System (M-MDS) display	Function	Initial setting	Setting contents	Control unit
LDWS Timing.	The distance between the warning-trigger lines of the Lane Departure Warning System (LDWS) and vehicle lane lines can be changed.	Adaptive	Adaptive/Early/Medium/Late	Forward sensing camera (FSC)
LDWS Warning	The warning operation sensitivity of the lane departure warning system (LDWS) can be changed.	Medium	Often/Medium/Rare	Forward sensing camera (FSC)
LDWS Volumn	The volume of the LDWS warning alarm can be changed.	Volume 1	Volume 1/Volume 2/Volume 3	Instrument cluster
LDWS Sound.	The type of the LDWS warning alarm can be changed.	Rumble Strip	Beep/Rumble Strip	Instrument cluster

Center display

Display of center display	Function	Initial setting	Setting contents	Control unit
Timing	The distance between the warning-trigger lines for the Lane Departure Warning System (LDWS) and vehicle lanes can be changed.	Before Line	At Line / Before Line	Forward sensing camera (FSC)
Warning	The warning operation sensitivity of the lane departure warning system (LDWS) can be changed.	Low	High / Low	Forward sensing camera (FSC)
Beep Volume	The volume of the LDWS warning alarm (Beep) can be changed.	Low	High / Low	Instrument cluster
Sound	The type of the LDWS warning alarm can be changed.	Rumble	Beep / Rumble	Instrument cluster

Temperature
Center display

Display of center display	Function	Initial setting	Setting contents	Control unit
Temp*1	The temperature unit can be changed.	F° or C°*2	F° / C°	Instrument cluster

Instrument cluster (without center display)

Instrument cluster LCD	Function	Initial setting	Setting contents	Control unit
°F or °C*1	The temperature unit can be changed.	°F or °C*2	°F / °C	Instrument cluster

*1 : When the ambient temperature display is switched, the set A/C cabin temperature display is also changed.
*2 : The initial value differs depending on the market.

Distance
Center display

Display of center display	Function	Initial setting	Setting contents	Control unit
Distance	The distance unit can be changed.	Miles or Km*3	Miles / Km	Instrument cluster

*3 : The initial value differs depending on the market.