FORWARD SENSING CAMERA (FSC) PERSONALIZATION FEATURES SETTING PROCEDURE

id092200033700

Caution

- **The personalization feature may not be set correctly if [Not equipped] is selected in the setting displayed on the M-MDS. Do not select [Not equipped] in the setting displayed on the M-MDS.**

Note

- Settings of some personalization features displayed on the M-MDS cannot be switched depending on the vehicle specification.

High Beam Control (HBC) System

Using M-MDS

1. Connect the M-MDS to the DLC-2.
2. After vehicle identification, select the following from the M-MDS initialization screen.
   (1) “Module programming“
   (2) “Programmable Parameters”
3. Select menu in the “FSC”.
4. Select an item name, and than select option.

Mazda Modular Diagnostic System (M-MDS) display	Function	Initial setting	Setting contents	Control unit
High Beam Control.	The high beam control (HBC) system can be switched between operable and inoperable.	ON	OFF / ON	Forward sensing camera (FSC)

Using center display

- For the setting procedure of the personalization features using the center display, refer to "CENTER DISPLAY PERSONALIZATION FEATURES". (See CENTER DISPLAY PERSONALIZATION FEATURES SETTING PROCEDURE.)

Lane Departure Warning System (LDWS)

Note

- For personalization of the warning sound and volume, refer to the INSTRUMENT CLUSTER PERSONALIZATION FEATURES SETTING PROCEDURE. (See INSTRUMENT CLUSTER PERSONALIZATION FEATURES SETTING PROCEDURE.)

Using M-MDS

1. Connect the M-MDS to the DLC-2.
2. After vehicle identification, select the following from the M-MDS initialization screen.
   (1) “Module programming“
   (2) “Programmable Parameters”
3. Select menu in the “FSC”.
4. Select an item name, and than select option.

Mazda Modular Diagnostic System (M-MDS) display	Function	Initial setting	Setting contents	Control unit
LDWS Timing.	The distance between the warning-trigger lines for the Lane Departure Warning System (LDWS) and vehicle lanes can be changed.	Adaptive	Adaptive / Early / Medium / Late	Forward sensing camera (FSC)
LDWS Warning.	The warning operation sensitivity of the lane departure warning system (LDWS) can be changed.	Medium	Often / Medium / Rare	Forward sensing camera (FSC)

Using center display

- For the setting procedure of the personalization features using the center display, refer to "CENTER DISPLAY PERSONALIZATION FEATURES". (See CENTER DISPLAY PERSONALIZATION FEATURES SETTING PROCEDURE.)