BLIND SPOT MONITORING (BSM) WARNING LIGHT REMOVAL/INSTALLATION

id092200041300

Note

- The blind spot monitoring (BSM) warning light are integrated into the outer mirror glass.
- For the blind spot monitoring (BSM) warning light removal/installation, refer to the outer mirror glass removal/installation. (See OUTER MIRROR GLASS REMOVAL.) (See OUTER MIRROR GLASS INSTALLATION.)