DTC TABLE [SKYACTIV-G 1.5 (L.H.D.)]

id100219000300

Caution

- **If there is any vehicle malfunction complaint lodged by a customer, refer to "FOREWORD" and perform CAN malfunction diagnosis following the steps in the troubleshooting procedure. (See FOREWORD [SKYACTIV-G 1.5 (L.H.D.)].)**

Note

- DTC is a capital “U”. The DTCs which are not described in the following table can be verified by the “Reference for initial letter of DTC is capital U”.

HS-CAN

DTC output module (M-MDS display)	DTC	Malfunction location	Reference for initial letter of DTC is capital U
PCM (PCM)	U0073:00	Unit communication error	(See DTC TABLE [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
	U0101:00	Communication error with TCM	
	U0121:00	Communication error with DSC HU/CM or ABS HU/CM	
	U0131:00	Communication error with EPS control module	
	U0140:00	Communication error with BCM	
	U0151:00	Communication error with SAS control module	
	U0155:00	Communication error with instrument cluster	
	U0214:00	Communication error with start stop unit	
	U0235:00	Communication error with laser sensor	
	U0298:00	Communication error with DC-DC converter (i-ELOOP)	
DSC HU/CM*1 (ABS)	U0001:88	Unit communication error	(See DTC TABLE [DSC HU/CM].)
	U0100:00	Communication error with PCM	
	U0101:00	Communication error with TCM	
	U0131:00	Communication error with EPS control module	
	U0151:00	Communication error with SAS control module	
	U0155:00	Communication error with instrument cluster	
	U0235:00	Communication error with laser sensor	
ABS HU/CM*2 (ABS)	U0001:88	Unit communication error	(See DTC TABLE [ABS HU/CM].)
	U0100:00	Communication error with PCM	
	U0101:00	Communication error with TCM	
	U0151:00	Communication error with SAS control module	
	U0155:00	Communication error with instrument cluster	
DC-DC converter (i-ELOOP)*3 (DCDC)	U0001:88	Unit communication error	(See DTC TABLE [i-ELOOP].)
	U0100:00	Communication error with PCM	
	U0140:00	Communication error with BCM	
	U0151:00	Communication error with SAS control module	
TCM*4 (TCM)	U0073:00	Unit communication error	(See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (CW6A-EL)].) (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (EW6A-EL)].)
	U0100:00	Communication error with PCM	
	U0121:00	Communication error with DSC HU/CM or ABS HU/CM	
	U0131:00	Communication error with EPS control module	
	U0155:00	Communication error with instrument cluster	
Auto leveling control module*5 (ALM)	U0001:88	Unit communication error	(See DTC TABLE [HEADLIGHT AUTO LEVELING SYSTEM].)
	U0100:00	Communication error with PCM	
	U0140:00	Communication error with BCM	
	U0155:00	Communication error with instrument cluster	

DTC output module (M-MDS display)	DTC	Malfunction location	Reference for initial letter of DTC is capital U
BCM (BCM)	U0001:88	Unit communication error	(See DTC TABLE [BCM].)
	U0100:00	Communication error with PCM	
	U0101:00	Communication error with TCM	
	U0121:00	Communication error with DSC HU/CM or ABS HU/CM	
	U0151:00	Communication error with SAS control module	
	U0155:00	Communication error with instrument cluster	
	U0214:00	Communication error with start stop unit	
	U023A:00	Communication error with forward sensing camera (FSC)	
Laser sensor*6 (SCBS)	U0001:00	Unit communication error	(See DTC TABLE [LASER SENSOR].)
	U0100:00	Communication error with PCM	
	U0121:00	Communication error with DSC HU/CM or ABS HU/CM	
	U0131:00	Communication error with EPS control module	
	U0155:00	Communication error with instrument cluster	
Forward sensing camera (FSC)*7 (FSC)	U0001:88	Unit communication error	(See DTC TABLE [FORWARD SENSING CAMERA (FSC)].)
	U0100:00	Communication error with PCM	
	U0121:00	Communication error with DSC HU/CM or ABS HU/CM	
	U0131:00	Communication error with EPS control module	
	U0140:00	Communication error with BCM	
	U0155:00	Communication error with instrument cluster	
	U0214:00	Communication error with start stop unit	
EPS control module (EPS)	U0001:88	Unit communication error	(See DTC TABLE [EPS CONTROL MODULE].)
	U0100:00	Communication error with PCM	
	U0121:00	Communication error with DSC HU/CM or ABS HU/CM	
	U0155:00	Communication error with instrument cluster	
	U0214:00	Communication error with start stop unit	
Start stop unit (SSU)	U0001:88	Unit communication error	(See DTC TABLE [START STOP UNIT].)
	U0028:87	Communication error with BCM	
	U0100:00	Communication error with PCM	
	U0101:00	Communication error with TCM	
	U0121:00	Communication error with DSC HU/CM or ABS HU/CM	
	U0121:87	Communication error with DSC HU/CM or ABS HU/CM	
	U0131:00	Communication error with EPS control module	
	U0140:00	Communication error with BCM	
	U0146:00	Communication error with BCM	
	U0151:00	Communication error with SAS control module	
	U0155:00	Communication error with instrument cluster	

DTC output module (M-MDS display)	DTC	Malfunction location	Reference for initial letter of DTC is capital U
Connectivity master unit (CMU) *8 (CMU)	U0001:88	Unit communication error	(See DTC TABLE [CONNECTIVITY MASTER UNIT].)
	U0100:00	Communication error with PCM	
	U0101:00	Communication error with TCM	
	U0121:00	Communication error with DSC HU/CM or ABS HU/CM	
	U0131:00	Communication error with EPS control module	
	U0140:00	Communication error with BCM	
	U0151:00	Communication error with SAS control module	
	U0155:00	Communication error with instrument cluster	
	U0182:00	Communication error with auto leveling control module	
	U0214:00	Communication error with start stop unit	
	U0235:00	Communication error with laser sensor	
	U023A:00	Communication error with forward sensing camera (FSC)	
SAS control module (RCM)	U0001:88	Unit communication error	(See DTC TABLE [STANDARD DEPLOYMENT CONTROL SYSTEM].) (See DTC TABLE [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
	U0100:00	Communication error with PCM	
	U0155:00	Communication error with instrument cluster	
Instrument cluster (IC)	U0001:88	Unit communication error	(See DTC TABLE [INSTRUMENT CLUSTER].)
	U0100:00	Communication error with PCM	
	U0101:00	Communication error with TCM	
	U0121:00	Communication error with DSC HU/CM or ABS HU/CM	
	U0131:00	Communication error with EPS control module	
	U0140:00	Communication error with BCM	
	U0151:00	Communication error with SAS control module	
	U0156:00	Communication error with connectivity master unit (CMU)	
	U0182:00	Communication error with auto leveling control module	
	U0214:00	Communication error with start stop unit	
	U0235:00	Communication error with laser sensor	
	U023A:00	Communication error with forward sensing camera (FSC)	

*1 : With DSC system
*2 : Without DSC system
*3 : With i-ELOOP
*4 : ATX
*5 : With headlight auto leveling system
*6 : With smart city brake support (SCBS)
*7 : With forward sensing camera (FSC)
*8 : With center display

MS-CAN

DTC output module (M-MDS display)	DTC	Malfunction location	Reference for initial letter of DTC is capital U
Instrument cluster (IC)	U0010:88	Unit communication error	(See DTC TABLE [INSTRUMENT CLUSTER].)
	U0232:00	Communication error with blind spot monitoring (BSM) control module (LH)	

DTC output module (M-MDS display)	DTC	Malfunction location	Reference for initial letter of DTC is capital U
Blind spot monitoring (BSM) control module (LH)*1 (BSM)	U0001:88	Unit communication error	(See DTC TABLE [BLIND SPOT MONITORING (BSM) SYSTEM].)
	U0100:00	Communication error with PCM	
	U0121:00	Communication error with DSC HU/CM or ABS HU/CM	
	U0155:00	Communication error with instrument cluster	
	U0214:00	Communication error with start stop unit	
Climate control unit*2 (EATC)	U0010:88	Unit communication error	(See DTC TABLE [FULL-AUTO AIR CONDITIONER].)
	U0155:00	Communication error with instrument cluster	

*1 : With blind spot monitoring (BSM) system
*2 : With full-auto air conditioner