PID/DATA MONITOR INSPECTION (i-stop) [SKYACTIV-D 1.5]

id1102b0000100

Note
- PIDs related to i-stop can be displayed in a list using the M-MDS data monitor diagnostic function.
- If the engine is stopped by the i-stop control while the following data monitor items on the M-MDS are being viewed, the data monitor items may no longer be displayed.
  - BRAKE_SW
  - BRK_F_P_C
  - LON_ACCL_C
  - WSPD_SEN_LF
  - WSPD_SEN_RF
  - WSPD_SEN_LR
  - WSPD_SEN_RR

1. Connect the M-MDS to the DLC-2.
2. After vehicle identification is completed, select the following from the M-MDS initial screen.
   (1) [Data logger]
   (2) [Powertrain]
   (3) [i-stop]
3. Select the applicable item from the PID/DATA Monitor Table.
4. Verify the monitored value according to the directions on the screen.

PID/DATA Monitor Table

Module	Item (definition)	Unit/Condition	
PCM	APP	%	(See PCM INSPECTION [SKYACTIV-D 1.5].)
	APP1	%	
	APP2	%	
	BARO	kPa	
	BATT_CUR	A	
	BATT_RES	Not applicable	
	BATT_SOC	%	
	BATT_TEMP	°C	
	BATT_V	V	
	BBP	kPa	
	BFP	kPa	
	BOO	High/Low	
	BPA	High/Low	
	CPP	%	
	CPP/PNP	OFF/ON	
	ECT	°C	
	FRP	kPa	
	IAT	°C	
	I-Stop_OFF	OFF/ON	
	I-Stop_TRD	OFF/ON	
	I-Stop_VSP	OFF/ON	
	I-Stop_VST	OFF/ON	
	M_GEAR	Neutral/1st gear/2nd gear/3rd gear/ 4th gear/5th gear/Reverse/ Undefined/ Auto/ In_Progress/ YSF/Error	
	VPWR	V	
DSC HU/CM	BRAKE_SW	OFF/ON	(See PID/DATA MONITOR TABLE [DSC HU/CM].)
	BRK_F_P_C	Pa	
	LON_ACCL_C	G	
	WSPD_SEN_LF	KPH	
	WSPD_SEN_LR	KPH	
	WSPD_SEN_RF	KPH	
	WSPD_SEN_RR	KPH	

TCM	I-Stop_EST	OFF/ON	(See ON-BOARD DIAGNOSTIC SYSTEM PID/DATA MONITOR INSPECTION [TCM (EW6A-EL)].)
	TFT	°C	
	TR	P/ SHIFT_DOWN/SHIFT_UP/ M/D/N/R	
Climate control unit	STOP_ST	Available/Not Available/ Error	(See PID/DATA MONITOR TABLE [FULL-AUTO AIR CONDITIONER].)
SAS control module	SEAT_B_D	Unbuckled/ Buckled	(See PID/DATA MONITOR TABLE [STANDARD DEPLOYMENT CONTROL SYSTEM].) (See PID/DATA MONITOR TABLE [TWO-STEP DEPLOYMENT CONTROL SYSTEM].)
BCM	DOOR_ALL	Close/OPEN	(See PID/DATA MONITOR TABLE [BCM].)
	DOOR_D	Close/OPEN	
	HOOD	Close/OPEN	
	TRUNK	Close/OPEN	
Start stop unit	RELAY_ACC	Off/On	(See PID/DATA MONITOR TABLE [START STOP UNIT].)
	RELAY_IG1	Off/On	
	RELAY_IG2	Off/On	
	SSB_1	Off/On	
	SSB_2	Off/On	
	VPWR_ACC	V	
	VPWR_B1	V	
	VPWR_IG1	V	
EPS	STR_AB_EST	°	(See PID/DATA MONITOR TABLE [EPS CONTROL MODULE].)
	STR_ROT_SPD	°/s	
	STR_TRQ_S_M	Nm	
DC-DC Converter (i-ELOOP)	BYPS_STAT	Bypass Off/ Bypass On/ Bypass Off fault/Bypass On fault	(See PID/DATA MONITOR INSPECTION [i-ELOOP].)
	DCDC_IN_V	V	