NO.2 i-stop WARNING LIGHT (AMBER) FLASHES [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id1103q1000700

2	i-stop WARNING LIGHT (AMBER) FLASHES
DESCRIPTION	• i-stop function is inhibited because an i-stop control system error is detected.
POSSIBLE CAUSE	**i-stop component parts malfunction** • Detects malfunction in i-stop component part (i-stop related module detects DTC) — PCM — Current sensor — Battery malfunction (deterioration) — Generator malfunction (part, system, control malfunction) — DC-DC converter — DSC HU/CM — SAS control module — TCM (ATX) **Number of times i-stop function operates exceeds assured operation amount of components** • Number of times engine restart exceed limit • Any of following parts exceeds assured operation amount: — Starter relay — Starter

Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	**VERIFY DTC** • Retrieve the PCM, DSC HU/CM, SAS control module and TCM DTCs using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) (See DTC INSPECTION [DSC HU/CM].) (See DTC INSPECTION [STANDARD DEPLOYMENT CONTROL SYSTEM].) (See DTC INSPECTION [TWO-STEP DEPLOYMENT CONTROL SYSTEM].) (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (CW6A-EL)].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) (See DTC TABLE [DSC HU/CM].) (See DTC TABLE [STANDARD DEPLOYMENT CONTROL SYSTEM].) (See DTC TABLE [TWO-STEP DEPLOYMENT CONTROL SYSTEM].) (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (CW6A-EL)].)
		No	Go to the next step.
2	**DETERMINE IF MALFUNCTION CAUSE IS BATTERY VOLTAGE DECREASE OR OTHER** • Start the engine and warm it up completely. • Idle the engine. • Access the BATT_SOC PID using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) • Is the BATT_SOC PID value **above 68 %**?	Yes	Go to Step 4.
		No	Go to the next step.
3	**INSPECT BATTERY** • Recharge the battery. (See BATTERY RECHARGING.) • Inspect the battery. (See BATTERY INSPECTION.) • Is there any malfunction?	Yes	Replace the battery. (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
		No	Go to the next step.
4	**INSPECT GENERATOR** • Inspect the generator. (See GENERATOR INSPECTION [WITHOUT i-ELOOP (SKYACTIV-G 1.3, SKYACTIV-G 1.5)].) (See GENERATOR INSPECTION [WITH i-ELOOP (SKYACTIV-G 1.3, SKYACTIV-G 1.5)].) • Is there any malfunction?	Yes	Repair or replace the malfunctioning part according to the inspection results.
		No	Replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)

STEP	INSPECTION	RESULTS	ACTION
5	Verify the test results. • If normal, return to the diagnostic index to service any additional symptoms. (See SYMPTOM DIAGNOSTIC INDEX [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) • If a malfunction remains, inspect the related Service Information and perform the repair or diagnosis. — If the vehicle is repaired, troubleshooting is completed. — If the vehicle is not repaired or additional diagnostic information is not available, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)		