NO.3 i-stop INDICATOR LIGHT (GREEN) FLASHES [SKYACTIV-D 1.5]

id1103q4000800

3	i-stop INDICATOR LIGHT (GREEN) FLASHES
DESCRIPTION	• i-stop indicator light (green) remains flashing during idling. (ATX, Except for European (L.H.D. U.K.) specs.) • i-stop indicator light (green) remains flashing during i-stop.
POSSIBLE CAUSE	**Note** • If the brake pedal depression is insufficient, the i-stop indicator light (green) illuminates and the i-stop function operates by increasing brake pedal depression. (ATX, Except for European (L.H.D. U.K.) specs.) • If in gear while i-stop is operating, the i-stop indicator light (green) flashes continuously. (MTX) • If the driver's door is open while i-stop is operating, the i-stop warning light (green) flashes continuously. (European (L.H.D. U.K.) specs.) **i-stop function operation conditions are not set** • False detection of insufficient brake depression (fluid pressure). (ATX, Except for European (L.H.D. U.K.) specs.) — Brake fluid pressure sensor (built-into DSC HU/CM) malfunction **i-stop indicator light (green) false illumination** • i-stop indicator light (green) illumination circuit malfunction in instrument cluster • CAN communication line between instrument cluster and PCM malfunction

Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	**VERIFY DTC** • Retrieve the PCM, DSC HU/CM and instrument cluster DTCs using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) (See DTC INSPECTION [DSC HU/CM].) (See DTC INSPECTION [INSTRUMENT CLUSTER].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 1.5].) (See DTC TABLE [DSC HU/CM].) (See DTC TABLE [INSTRUMENT CLUSTER].)
		No	ATX: • Go to the next step. MTX: • Go to Step 3.
2	**INSPECT BRAKE FLUID PRESSURE SENSOR** • Inspect the brake fluid pressure sensor. (See BRAKE FLUID PRESSURE SENSOR INSPECTION.) • Is there any malfunction?	Yes	Replace the DSC HU/CM. (See DSC HU/CM REMOVAL/INSTALLATION [L.H.D.].) (See DSC HU/CM REMOVAL/INSTALLATION [R.H.D.].)
		No	Go to the next step.
3	**INSPECT INSTRUMENT CLUSTER** • Inspect the instrument cluster. (See INSTRUMENT CLUSTER INSPECTION.) • Is there any malfunction?	Yes	Replace the instrument cluster. (See INSTRUMENT CLUSTER REMOVAL/INSTALLATION.)
		No	Repeat the inspection from Step 1. • If the malfunction is not resolved, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 1.5].) Go to the next step.
4	Verify the test results. • If normal, return to the diagnostic index to service any additional symptoms. (See SYMPTOM DIAGNOSTIC INDEX [SKYACTIV-D 1.5].) • If a malfunction remains, inspect the related Service Information and perform the repair or diagnosis. — If the vehicle is repaired, troubleshooting is completed. — If the vehicle is not repaired or additional diagnostic information is not available, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)		