ACTIVE COMMAND MODES INSPECTION [i-ELOOP]

id130201000600

1. Connect the M-MDS to the DLC-2.
2. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.
   (1) Select “DataLogger”.
   (2) Select “Modules”.
   (3) Select “DCDC”.
3. Select the simulation items from the PID table.
4. Using the active command modes function, inspect the operation of each part.
   - If the operation of output parts cannot be verified after the active command mode inspection is performed, this could indicate the possibility of an open or short circuit, sticking, or operation malfunction in the output parts.

Item	Operating part	Condition/Specification
CHARGE_FLG	CAPACITOR (i-ELOOP)	Select OFF/ON to set the quick charge function when replacing the capacitor.