GENERATOR DISASSEMBLY/ASSEMBLY [WITH i-ELOOP (SKYACTIV-G 1.3, SKYACTIV-G 1.5)]

id1317040050q9

1. Disassemble in the order indicated in the table.