HB-2 dry block heater user manual

Fictional document for Northfield Lab Supply, a fictional company created for a portfolio project. Not for real use.

Item	Value
Document ID	NLS-DOC-HB2-MAN-R1
Product	Dry Block Heater HB-2
Applies to	NLS-HB2-SNG, NLS-HB2-DBL
Revision	R1
Effective date	2026-03-01
Status	current

1. Introduction

The HB-2 is a digital dry block heater with interchangeable blocks. It is sold in two versions: the Single block and the Dual block, which has two independently controlled blocks.

Differences between the versions:

	Single block	Dual block
Blocks	One block for 20 × 1.5 ml tubes	Two blocks, each for 20 × 1.5 ml tubes
Temperature control	One	Two, independent
Power	150 W	280 W
Warranty	1 year	2 years

2. Safety

- The blocks reach 150 °C. Do not touch a hot block; use the block handle or wait until it is cool.
- Do not heat flammable liquids.
- Use only the blocks supplied with the unit, and do not use damaged blocks.
- Place on a heat-resistant surface with clear space around the unit.
- Switch off and unplug before changing blocks.

3. Setting up

1. Check the contents against the packing list.
2. Place the heater on a level, heat-resistant surface.
3. Fit the block(s) into the unit; no tools are needed.
4. Connect the mains cable (230 V AC, 50 Hz).

4. Operation

1. Switch on and set the temperature (Dual block: set each block separately).
2. Wait until the display shows the set temperature and allow about 10 minutes to stabilise.
3. Place the tubes in the block wells so they touch the bottom.
4. Set the timer if required and start the run.
5. Switch off and let the block cool before removing or cleaning.

5. Cleaning and maintenance

- Wipe the unit with a damp cloth when cool.
- Clean the block wells with a swab and 70 % ethanol.
- Do not immerse the unit in liquid.

6. Troubleshooting

Problem	Likely cause	What to do
Display shows an error	Over-temperature cut-out	Switch off, let the unit cool and restart
Temperature not reached	Block not seated	Reseat the block
Does not switch on	Mains cable not connected	Check the cable and socket

7. Warranty and contact

Warranty: Single block: 1 year. Dual block: 2 years.

Warranty claims: contact Customer service with the order number and a description of the fault. The warranty covers manufacturing defects and does not cover damage from misuse, spills or unauthorised repair.

Contact: customerservice@northfieldlabsupply.example