MC-10 microcentrifuge user manual

Fictional document for Northfield Lab Supply, a fictional company created for a portfolio project. Not for real use.

SUPERSEDED. Replaced by NLS-DOC-MC12-MAN-R1. Not to be used as current.

Item	Value
Document ID	NLS-DOC-MC10-MAN-R1
Product	Benchtop Microcentrifuge MC-10
Applies to	NLS-MC10-BAS
Revision	R1
Effective date	2024-06-01
Status	superseded

1. Introduction

The MC-10 Basic is a discontinued benchtop microcentrifuge with a 10-place rotor for 1.5 ml tubes and one fixed speed. It has been replaced by the MC-12 Standard.

2. Safety

- Place the unit on a level, stable surface.
- Never run with an unbalanced load or with the lid open.
- Unplug before cleaning or moving.

3. Setting up

1. Check the contents: unit, 10-place rotor, mains cable (UK plug).
2. Connect the mains cable (230 V AC, 50 Hz).
3. Fit the rotor and tighten the nut by hand.

4. Operation

1. Load tubes in opposite positions and balance odd numbers with a water-filled tube.
2. Close the lid and press Start. The unit runs at 12,000 rpm (10,800 ×g).
3. Wait for the rotor to stop before opening the lid.

5. Cleaning and maintenance

- Wipe with a damp cloth and mild detergent. Do not autoclave the rotor.

6. Troubleshooting

Problem	Likely cause	What to do
Does not start	Lid not latched	Close the lid until it clicks
Vibration	Unbalanced tubes	Rebalance the tubes

7. Warranty and contact

Warranty: 1 year.

Warranty claims: contact Customer service with the order number and a description of the fault. The warranty covers manufacturing defects and does not cover damage from misuse, spills or unauthorised repair.

Contact: customerservice@northfieldlabsupply.example