

Author: Colognato Stefano

MCF88 DATA FRAME FORMAT

time sync and removed threshold
ssage
ssage
essage ified
r centage to tprh and kamstrup
pensation
ultrasound, ModBus, Davis
scription
node
SYNC UL
period counters
nessage
)



Author: Colognato Stefano

The document describes encryptions related to LoRaWAN™ payloads. Relevant chapters per product of interest are marked with a cross "X".

1. UPLINK MESSAGES from END-DEVICES

PRODUCT PART NUMBER	1.1 TIME SYNC REQUEST	1.2 T/P/RH	1.3 UART	1.4 POWER	1.510	1.6 REPORT DATA	1.7 T/P/TH/LUX/VOC	1.8 ANALOG DATA	1.9 T/P/RH/LUX/VOC/CO2	1.10 SPECIAL DATA	1.11 DIGITAL DATA	1.12 SERIAL DATA	1.13 LENGTH ERROR
MCF-LW06485	Х					Х							Χ
MCF-LW06VMC	Х												Х
MCF-LW06VMC2	Х												Х
MCF-LW06232	Х		Х									Х	Х
MCF-LW06CNT/B	Х										Х		Х
MCF-LW06420/D	Х							Х					Х
MCF-LW06010/D	Х							Х					Х
MCF-LW06424/D	Х							Х					Х
MCF-LW06420B	Х							Х					Х
MCF-LW06010B	Х							Х					Х
MCF-LW06424B	Х							Х					Х
MCF-LW06420T	Х							Х			Х		Х
MCF-LW06010T	Х							Х			Х		Х
MCF-LW06424T	Х							Х			Х		Х
MCF-LW06KIO	Х		Х		Х					Х	Х	Х	Х
MCF-LW06DO	Х		Х		Х						Х	Х	Х
MCF-LW12PLG	Х			X	Х								Х
MCF-LW12MET	Х			Х	Х						Х		Х
MCF-LW13IO	Х				Х						Х		Х
MCF-LW13MIO	Х				Х						Χ		Х
MCF-LW12TERWP	Х	Х											Χ
MCF-LW12TERPM	Х					Х							Х
MCF-LW12TER	Х	Х											Х
MCF-LW12VOC	Х						Х						Х
MCF-LW12CO2	Х								Х				Х
MCF-LWWS00	Х					Х							Х
MCF-LWWS01	Х					Х							Х
MCF-LW06DAVK/P	Х					Х							Χ



Author: Colognato Stefano

2. DOWNLINK MESSAGES to END-DEVICES

PRODUCT PART NUMBER	2.1 TIME SYNC ANSWER	2.2 UART	2.3 IO MESSAGE	2.4 SET PERIOD	2.5 METERING REQUEST	2.6 SET PRESSURE COMPENSATION	2.7 THRESHOLDS	2.8 SERIAL DATA	2.9 OFF COMMAND
MCF-LW06485	Х			Х				Х	Х
MCF-LW06VMC	Х			Х					Х
MCF-LW06VMC2	Х			Х					Х
MCF-LW06232	Х	Х		Х				Х	Х
MCF-LW06CNT/B				Х					
MCF-LW06420/D/T	Х			Х			Х		Χ
MCF-LW06010/D/T	Х			Х			Х		Χ
MCF-LW06424/D/T	Х			Х			Х		Х
MCF-LW06420B	Х			Х					Х
MCF-LW06010B	Х			Х					Х
MCF-LW06424B	Х			Х					Х
MCF-LW06KIO	Х	Х	Х	Х				Х	Х
MCF-LW06DO	Х	Х	Х	Х				Х	Х
MCF-LW12PLG	Х		Х	Х	Х		Х		Х
MCF-LW12MET	Х		Х	Х	Х		Х		Х
MCF-LW13IO	Х		Х	Х					Х
MCF-LW13MIO	Х		Х	Х					Х
MCF-LW12TERWP	Х			Х		Х			Х
MCF-LW12TERPM	Х			Х		Х			Х
MCF-LW12TER	Х			Х		Х			Х
MCF-LW12VOC	Х			Х		Х			Х
MCF-LW12CO2	Х			Х		Х			Х
MCF-LWWS00	Х			Х					Х
MCF-LWWS01	Х			Х					Х
MCF-LW06DAVK/P	Х			Х					Х



Author: Colognato Stefano

1. UPLINK MESSAGES FROM END-DEVICES

HOME

1.1 TIME SYNC REQUEST

HOME

name	size [byte]	hex value	meaning
Uplink ID	1 byte	01	Time sync request
Sync ID	4 byte	XX XX XX XX	ID of sync request
Sync Version	3 byte (optional)	XX XX XX	Major and minor version and build
		02 00	for MCF-LW06VMC
		02 01	for MCF-LW06232
		02 02	for MCF-LW06KAM
		02 03	for MCF-LW06485
		02 04	for MCF-LWWS00 and MCF-LW06DAVK
		02 05	for MCF-LW06KIO
		02 06	for MCF-LW12WAM
		02 07	for MCF-LW06420/010 OBSOLETE
		02 08	for MCF-LWWS01 and MCF-LW06DAVKP
		02 09	for MCF-LW06420
		02 0A	for MCF-LW06010
		02 0B	for MCF-LW06424
		02 0C	for MCF-LW06420D
		02 0D	for MCF-LW06010D
		02 0E	for MCF-LW06424D
		02 0F	for MCF-LW06VMC2
Application	0 5.4-	02 10	for MCF-LW06420B
type	2 byte	02 11	for MCF-LW06010B
		02 12	for MCF-LW06424B
		02 13	for MCF-LW06CNT
		02 14	for MCF-LW06CNTB
		02 15	for MCF-LW06010T
		02 16	for MCF-LW06420T
		02 17	for MCF-LW06424T
		02 18	for MCF-LW06DO
		04 00	for MCF-LW12TER
		04 01	for MCF-LW12TERWP
		04 02	for MCF-LW12VOC
		04 03	for MCF-LW12CO2
		04 05	for MCF-LW12TERPM
		07 00	for MCF-LW12MET
		07 01	for MCF-LW13IO
		07 02	for MCF-LW12PLG
		09 00	for MCF-LW13MIO
Option	1 byte (optional)	xx	bit 0 set if first message after boot
Οριίστ	i byte (optional)	^^	bit 1 set if external power is going down



MCF88 DATA FRAME FORMAT 1.23

Author: Colognato Stefano

RFU	X byte	XX	Optional RFU byte
-----	--------	----	-------------------

The device, after sending the message, waits for the time sync answer (2.1 TIME SYNC ANSWER). If nothing received, it will try to send the request a couple of times. If error persists, it will try again after a few hours.

If it receives the right answer, it aligns the internal clock and a new sync message will be sent after a week to overcome real time clock drift.

Example

message after a power-on: 01787d3c25000200020301

message during a power down (only for MCF-LW06xxx family class C): 014e7d3c25000200020302

1.2 T/P/RH HOME

name	size [byte]	hex value	meaning
Uplink ID	1 byte	04	Temperature/Pressure/Humidity
	10 byte	XX XX	Measure 1, refer to Note 1
Data	10 byte	XX XX	Measure 2, refer to Note 1
	10 byte	XX XX	Measure 3, refer to Note 1
Batt %	1 byte (optional)	XX	Battery percentage
RFU	4 byte (optional)	XX XX XX XX	Optional RFU byte

Note 1:

The 10 bytes for each measurement are divided as follows:

- > 4 bytes are for the date and time. The MSB (most significant byte) is on the right so they must be read from the right. The 4 byte in reverse order are as follows:
 - 7 bit for the offset of the year, starting from the year 2000
 - 4 bit per month
 - 5 bit for day of the month
 - 5 bits for hour
 - 6 bits for minutes
 - 5 bits for half the seconds. The seconds range is from 0 to 31, so the result should be multiplied by 2 to find the actual seconds of the measurement.
- 2 bytes for temperature. The temperature is represented by a signed integer with the least significant byte first. The temperature is expressed in hundreds of a °C degree.
- 1 byte for humidity. Relative humidity is an unsigned integer corresponding to twice the percentage of humidity.
- 3 bytes for pressure. Pressure is an unsigned integer with the least significant byte first; it is expressed in Pascal.



MCF88 DATA FRAME FORMAT 1.23

Author: Colognato Stefano

Example

Sample payload:

04dc7e3721b40a47608801dd7e3721b10a43608801e07e3721b20a425d8801

Remove the first byte and divide the other 30 into 3 parts by 10 byte that correspond to 3 measurements.

The 3 measurements will be:

- dc7e3721b40a47608801
- dd7e3721b10a43608801
- e07e3721b20a425d8801

Decipher the first measurement dividing it by groups and applying the necessary transformations:

- Measurement date: dc 7e 37 21
 - Byte swapping, result: 21 37 7e dc
 - The result in bits will be: 00100001 00110111 01111110 11011100
 - The bits are divided as explained above

Year: 0010000 ♦ Result: 16 **>** 2000+16 = 2016 Month: 1001 ♦ Result: 9 Day: 10111 ♦ Result: 01111 Hour: ♦ Result: 15 Minutes:110110 ♦ Result: Seconds: 11100 ♦ Result: 28

- The date of the measurament will be: 23/09/2016 15:54:56.
- Temperature: b40a
 - Byte swapping, result: 0ab4
 - The result (with sign) will be +2740 with two decimal places, then + 27.40 °C.
- Humidity: 47
 - In decimal is 71, the humidity is 71/2 = 35.5% rH.

≥ 28*2 = 56

- o Pressure: 608801
 - Byte swapping, result: 018860
 - In decimal, the result is 100448, with two decimal places the pressure is 1004.48 hPa.

1.3 UART <u>HOME</u>

name	size [byte]	hex value	meaning
Uplink ID	1 byte	05	UART
Data	Application related	XX XX	Data to be forwarded, message sent via serial or usb command.



MCF88 DATA FRAME FORMAT 1.23

Author: Colognato Stefano

1.4 POWER HOME

The recurrent message of metering end-nodes is as follows:

name	size [byte]	hex value	meaning
Uplink ID	1 byte	09	Power
Date/Time	4 byte	XX XX XX XX	Date and time (as for Note 1)
Active energy	4 byte (s32 LSB)	XX XX XX XX	Cumulative Active energy (Wh)
Reactive energy	4 byte (s32 LSB)	XX XX XX XX	Cumulative Reactive energy (VARh)
Apparent energy	4 byte (s32 LSB)	XX XX XX XX	Cumulative Apparent energy (VAh)
Running Time	4 byte (u32 LSB)	XX XX XX XX	Seconds of running (s)

After a message of metering request (2.5 METERING REQUEST), or enabled on the sensor, the uplink is as follows:

name	size [byte]	hex value	meaning
Uplink ID	1 byte	09	Power
Date/Time	4 byte	XX XX XX XX	Date and time (as for Note 1)
Active energy	4 byte (s32 LSB)	XX XX XX XX	Cumulative Active energy (Wh)
Reactive energy	4 byte (s32 LSB)	XX XX XX XX	Cumulative Reactive energy (VARh)
Apparent energy	4 byte (s32 LSB)	XX XX XX XX	Cumulative Apparent energy (VAh)
Active power	2 byte (s16 LSB)	XX XX	Active power (W)
Reactive power	2 byte (s16 LSB)	XX XX	Reactive power (VAR)
Apparent power	2 byte (s16 LSB)	XX XX	Apparent power (VA)
Voltage	2 byte (u16 LSB)	XX XX	Voltage (dV RMS)
Current	2 byte (u16 LSB)	XX XX	Current (mA RMS)
Period	2 byte (u16 LSB)	XX XX	Period (us)
Running Time	4 byte (u32 LSB)	XX XX XX XX	Seconds of running (s)

1.5 IO HOME

name	size [byte]	hex value	meaning
Uplink ID	1 byte	0A	Input/output
Date/Time	4 byte	XX XX XX XX	Date and time (as for Note 1)
Inputs	4 byte (u32 LSB)	XX XX XX XX	Bit mask of the inputs
Outputs	4 byte (u32 LSB)	XX XX XX XX	Bit mask of the outputs
Events	4 byte (u32 LSB)	XX XX XX XX	Bit mask of input events

This uplink format is for 32 inputs and 32 outputs. Relevant bits depend on the device part number and its I/O capability. In case of MCF-LW12PLG, the input status represents the status of the mains (1 for mains present, 0 for mains not present).

1.6 REPORT DATA

HOME

name	size [byte]	hex value	meaning
Uplink ID	1 byte	0B	Report data



Author: Colognato Stefano

	OY	for MCF-LW06KAM, "Y" is the sequential number of the transmission in progress, is incremented at the end of each transmission.
	1Y/4Y	for MCF-LW06485, "Y" is the sequential number of the transmission in progress, is incremented at the end of each transmission, refer to Note 2
1 byte 2Y	2Y	for MCF-LWWS00, MCF-LWWS01, MCF-LW06DAVK and MCF-LW06-DAVKP, "Y" is the sequential number of the transmission in progress, is incremented at the end of each transmission.
	3Y	for MCF-LW12TERPM, "Y" is the sequential number of the transmission in progress, is incremented at the end of each transmission.
1 byte	xx	Progressive frame index, increased at each transmission with the same identifier
133 byte	XX XX	for MCF-LW06485 refer to Note 2 for MCF-LWWS00 refer to Note 3 for MCF-LW06DAVK refer to Note 3 for MCF-LWWS01 refer to Note 4 for MCF-LW06DAVKP refer to Note 4 for MCF-LW12TERPM refer to Note 4A
	1 byte	1Y/4Y 1 byte 2Y 3Y 1 byte XX

Note 2:

Report ID for ModBus:

- 1Y for recurrent data;
- 4Y for data received after a 0x8 serial data downlink.

The ModBus frame consists of at least 3 bytes.

In case of error, it will return 0200XX where XX indicates the type of error:

- 0x05 configuration error
- 0x07 error reading internal configuration
- 0x7F ModBus command not implemented
- 0xCC communication error

In case of success, the first two bytes (us16 LSB) indicate the length (including the two bytes) and the remaining bytes is the data read from the peripheral Modbus device(s).

Example

Sample payload: 0b10000a00be87424808010000



Author: Colognato Stefano

Uplink ID: 0b

Report ID: 10 (recurrent data)

Frame ID: 00

Data: 0a00be87424808010000

Byte 1...2: 0a00 (LSB) -> 0x000a data length
Bit 3...10: be87424808010000 data content

Note 3:

The Davis weather station frame is made up of at least 4 bytes.

In the event of an error it returns XXYYZZZZ , where XX indicates the data version, YY the type of error (see Note 2), ZZZZ the size of the read data.

If case of successful reading of weather data, the data sequence will be as in the following table, data with more than 1 bytes is LSB:

name	size [byte]	meaning	
Data version	1 byte	Current version is 0	
Davis type	1 byte	16 (0x10) for Vantage Pro/Pro2	
Barometer data	2 byte (u16 LSB)	Unit is mHg (Hg/1000)	
Outside temperature	2 byte (d to LOB)	Unit is d°F (°F/10)	
Wind speed	1 byte	Unit is mph (miles per hour)	
Avg wind speed	1 byte	Unit is mph	
Wind direction	2 byte	Value from 1 to 360 degrees. (0° is no wind data, 90° is East, 180° is South, 270° is West and 360° is north)	
Outside humidity	1 byte	Relative humidity in %	
Rain rate	2 byte	Number of rain clicks (0.2mm or 0.01in). inches/hour	
UV	1 byte	Unit is in UV index	
Solar radiation	2 byte	The unit is in watt/meter2	
Day rain	2 byte	Number of rain clicks (0.2mm or 0.01in)	
Day et	2 byte	Unit is inch / 1000	
Soil moisture	4 byte	Unit is in centibar. It supports four soil sensors.	
Leaf wetness	4 byte	Number from 0 to 15 with 0 meaning very dry and 15 meaning very wet. It supports four leaf sensors.	
Forecast icons	1 byte	Single Bit meaning is: 0x01 = Rain 0x02 = Cloud 0x04 = Partly cloudy 0x08 = Sun 0x10 = Snow Mixed forecasts are possible. See examples	
Bar trend	1 byte	below. Signed byte that indicates the current 3-hour barometer trend. It is one of these values: -60 = Falling Rapidly = 196 (as an unsigned byte) -20 = Falling Slowly = 236 (as an unsigned byte) 0 = Steady 20 = Rising Slowly	



Author: Colognato Stefano

		60 = Rising Rapidly 80 = ASCII "P" = no trend info is available Any other value meanings that the Vantage does not have the 3 hours of bar data needed to determine the bar trend.
RFU	3 byte	Optional RFU bytes. Only present in MCF-LWWS01 and MCF-LW06DAVKP



MCF88 DATA FRAME FORMAT 1.23

Author: Colognato Stefano

Examples of Forecast icons:

decimal	hex	Segments shown	Forecast
8	80x0	Sun	Mostly Clear
6	0x06	Partial Sun + Cloud	Partially Cloudy
2	0x02	Cloud	Mostly Cloudy
3	0x03	Cloud + Rain	Mostly Cloudy, Rain within 12 hours
18	0x12	Cloud + Snow	Mostly Cloudy, Snow within 12 hours
19	0x13	Cloud + Rain + Snow	Mostly Cloudy, Rain or Snow within 12 hours
7	0x07	Partial Sun + Cloud + Rain	Partly Cloudy, Rain within 12 hours
22	0x16	Partial Sun + Cloud + Snow	Partly Cloudy, Snow within 12 hours
23	0x17	Partial Sun + Cloud + Rain + Snow	Partly Cloudy, Rain or Snow within 12 hours

Note 4:

Refer first to Note 3. In addition are PM readings are on a separate uplink. The field "Data", in case of success, is as follow:

- ➤ 4 bytes are for the date and time (as per Note 1)
- 6 bytes are for PM measures: 2 bytes for each measurement, formatted as LSB, reporting in order pm1.0, pm2.5 and pm10 in μg/m3

Note 4A:

The 16 bytes of Data are divided as follows:

- ➤ 4 bytes are for the date and time. The MSB (most significant byte) is on the right so they must be read from the right. The 4 byte in reverse order are as follows:
 - 7 bit for the offset of the year, starting from the year 2000
 - 4 bit per month
 - 5 bit for day of the month
 - 5 bits for hour
 - 6 bits for minutes
 - 5 bits for half the seconds. The seconds range is from 0 to 31, so the result should be multiplied by 2 to find the actual seconds of the measurement.
- > 2 bytes for temperature. The temperature is represented by a signed integer with the least significant byte first. The temperature is expressed in hundreds of a °C degree.
- 1 byte for humidity. Relative humidity is an unsigned integer corresponding to twice the percentage of humidity.
- > 3 bytes for pressure. Pressure is an unsigned integer with the least significant byte first; it is expressed in Pascal.
- 6 bytes are for PM measures: 2 bytes for each measurement, formatted as LSB, reporting in order pm1.0, pm2.5 and pm10 in μg/m3.



MCF88 DATA FRAME FORMAT 1.23

Author: Colognato Stefano

Example

Sample payload:

0b3a006caf51266409338b8701170022002a00

Uplink ID: 0b Report ID: 3a Frame ID: 00

Data: 6caf5126 6409 33 8b8701 1700 2200 2a00

- o date and time are: 6c af 51 26
 - Byte swapping, result: 26 51 af 6c
 - The result in bits will be: 00100110 01010001 10101111 01101100
 - The bits are divided as explained above

Year: 0010011
 Result: 19
 ≥ 2000+19 = 2019
 Month: 0010

North.
 Result:
 Day:
 Result:
 Hour:
 Result:
 2
 10001
 10101
 Result:
 21

Minutes:111011

◆ Result: 59

Seconds: 01100

Nesult: 12→ 12*2 = 24

- The date of the measurament will be: 17/02/2019 21:59:24.
- o Temperature: 6409
 - Byte swapping, result: 0964
 - The result (with sign) will be +2404 with two decimal places, then +24.04 °C.
- o Humidity: 33
 - In decimal is 51, the humidity is 51/2 = 25.5% rH.
- o Pressure: 8b8701
 - Byte swapping, result: 01878b
 - In decimal, the result is 100235, with two decimal places the pressure is 1002.35 hPa.
- o *PM1: 1700*
 - Byte swapping, result: 0017
 - In decimal, the result is 23, the PM1 value is 23 μg/m3.
- o PM2.5: 2200
 - Byte swapping, result: 0022
 - In decimal, the result is 34, the PM1 value is 34 μg/m3.
- o PM10: 2a00
 - Byte swapping, result: 002a
 - In decimal, the result is 42, the PM1 value is 42 μg/m3.



MCF88 DATA FRAME FORMAT 1.23

Author: Colognato Stefano

1.7 T/P/RH/LUX/VOC

HOME

name	size [byte]	hex value	meaning
Uplink ID	1 byte	0C	Temperature/Pressure/Humidity/Lux/Voc
Data	14 byte	XX XX	Measure 1, refer to Note 5
	14 byte	XX XX	Measure 2, refer to Note 5
Batt %	1 byte (optional)	XX	Battery percentage
RFU	6 byte (optional)	XX XX XX XX	Optional RFU byte

Note 5:

The first 10 bytes for each measurement are the same as defined in Note 1, the following 4 bytes are as follows:

- > 2 bytes for illuminance. Luminance is represented by an unsigned integer with the least significant byte first. The Luminance is reported in lux (lx).
- > 2 bytes for VOC (Volatile organic compounds). The VOC level is reported according to setup of the device made with LoRaTool APP, as unsigned with the least significant byte first:
 - o index (IAQ indoor air quality) between 0 (clean air) and 500 (heavily polluted air)
 - o bVOC value between 500ppb (clean air) and 50000ppb (heavily polluted air)

1.8 ANALOG DATA

HOME

name	size [byte]	hex value	meaning
Uplink ID	1 byte	0D	Analog data
	00	for MCF-LW12WAM	
Type	1 byto	01	for MCF-LW06420,MCF-LW06420D,MCF-LW06420B
туре	Type 1 byte	01	for MCF-LW06010,MCF-LW06010D,MCF-LW06010B
	01	for MCF-LW06424,MCF-LW06424D,MCF-LW06424B	
Data	134 byte	XX XX XX	Refer to Note 6

Note 6:

Data are as follow:

- 4 bytes are for the date and time (as per Note 1)
 - > 8 byte for measurements, 2 byte for each measurement, formatted as LSB with the following meaninging:
 - Bit 0..11: measured value, to be rescaled according to the type
 - Bit 12: equal to 1 if error: if the measured value is 0 meanings sensor disconnected (4-20mA only);
 greater or equal to 0xF00 it is a generic measurement error
 - Bit 13..14: measure type:
 - 0: 4-20 mA
 - 1: 0-10 V
 - 2: 0-5 V
 - Bit 15: RFU
 - 1 byte (optional) for battery percentage, only for MCF-LW06420B, MCF-LW06010B, MCF-LW06424B.



MCF88 DATA FRAME FORMAT 1.23

Author: Colognato Stefano

1.9 T/P/RH/LUX/VOC/CO2

HOME

name	size [byte]	hex value	meaning
Uplink ID	1 byte	0E	T/P/rH/Voc/Lux/Co2
Data	16 byte	XX XX	Measure 1, refer to Note 7
	16 byte	XX XX	Measure 2, refer to Note 7
Batt %	1 byte (optional)	XX	Battery percentage
RFU	2 byte (optional)	XX XX	Optional RFU byte

Note 7:

Data are as follow:

- ➤ The first 14 bytes for each measurement are the same as defined in Note 5
- Following 2 bytes are for CO2. CO2 concentration is represented by an signed integer with the least significant byte first. The CO2 is expressed in ppm.

1.10 SPECIAL DATA

HOME

name	size [byte]	hex value	meaning
Uplink ID	1 byte	0F	Special data
Туре	1 byte	00	Card Data message
Data	132 byte	XX XX	for Card Data message refer to Note 8

Note 8:

Data are as follow:

- ➤ 4 bytes for the date and time (as per Note1)
- > 1 byte for communication status:
 - Bit 0 (mask 0x01): equal to 1 is communication with the reader is OK
 - Bit 4 (mask 0x04): equal to 1 if card present

If card present, data frame also contains:

- ➤ 1 byte card identifier: equal to 0x01 for ISO14443 type
- 1 byte for UID legth
- 1 byte for SAK number
- n byte for UID



MCF88 DATA FRAME FORMAT 1.23

Author: Colognato Stefano

Example

Sample payload: 0f006caf512611010408447b8043

Uplink ID: 0f Type: 00

Date and time: 6caf5126

• The date of the measurement will be: 17/02/2019 21:59:24.

Communication status: 11

• bit 0 = 1 (communication OK), bit 4 = 1 (card present)

Card identifier: 01 UID Length: 04 SAK byte: 08 UID: 447b8043

1.11 DIGITAL DATA

HOME

name	size [byte]	hex value	meaning
Uplink ID	1 byte	10	Digital data
	1 byte	00	Input counters type 1
Туре	1 byte	01	Frequency meter
	1 byte	02	Input counters type 2
Data	133 byte	xx xx	For input counters message refer to Note 9 For frequency meter message refer to Note 10

Note 9:

Type 1: 2 bytes (LSB) per input counter (inputs 1 to 16).

Type 2: 30 byte for 5 measures (6 byte for every measure, 4 bytes date and time as defined in Note 1, 2 bytes LSB for counter value) and 1 byte (optional) for battery percentage.

Note 10:

4 bytes for the date and time, 2 bytes (LSB) for frequency value (base 0.1Hz), 1 byte (optional) for battery percentage.

MCF88 DATA FRAME FORMAT 1.23

Author: Colognato Stefano

1.12 SERIAL DATA

HOME

name	size [byte]	hex value	meaning
Uplink ID	1 byte	11	Serial data
Data Option	2 byte	XX XX	Refer to Note 11
Data	033 byte	XX XX	Data received, refer to Note 11.

Note 11:

Data Option is LSB and formatted as follow:

- Bit 0..11: index of the first byte of the current frame
- bits 12...15:
 - o 0x0 standard payload
 - o 0x8 last frame of the buffer
 - o 0x4 one BUFFER DOWNLINK frame missing, offset reports the expected one
 - o 0x2 BUFFER DOWLINK frame too big, exceeds internal buffer
 - o 0xE full buffer successfully saved (only after 0xC downlink type)

Data received from the device are buffered and sent via LoRa starting with index 0.

Maximum data length is 1024 bytes.

Empty data means receiving errors on RS232.

Example

Sample payload:

1100000103F4000400010324010400010334010400010366010200010376010200010380 1121000102000103880102000103900102000103A8010200FF6604000000020301000700 114280000000000000

Uplink ID: 11 Data option: 0000

• Bit 0...11:0x000 first byte index = 0

Bit 12...15: 0x0 standard payload

Data: 0103F4000400010324010400010334010400010366010200010376010200010380

Uplink ID: 11 Data option: 2100

• Bit 0...11:0x021 first byte index = 33

Bit 12...15: 0x0 standard payload

Data: 0102000103880102000103900102000103A8010200FF6604000000020301000700

Uplink ID: 11 Data option: 4280

• Bit 0...11:0x042 first byte index = 66

Bit 12...15: 0x8 last frame of the buffer

Data: 00000000000000



Author: Colognato Stefano

1.13 LENGTH ERROR

HOME

name	size [byte]	hex value	meaning
Uplink ID	1 byte	EE	LENGTH ERROR
Туре	1 byte	XX	Optional RFU byte
Data	19 byte	XX XX	Optional RFU byte

In case the sensor's frame length is too long for the selected datarate (eg. for AS923, US915 devices).



MCF88 DATA FRAME FORMAT 1.23

Author: Colognato Stefano

2. DOWNLINK MESSAGES TO END-DEVICES

HOME

2.1 TIME SYNC ANSWER

HOME

name	size [byte]	hex value	meaning
Downlink ID	1 byte	00	Time sync answer
Sync ID	4 byte	XX XX XX XX	Copy of received Sync ID
Date/time	4 byte	XX XX XX XX	Date/time GMT, refer to Note 12

Note 12:

Date/time GMT in DOS format with epoch 2000. Sent as LSB. In bits, will be:

- > 7 bits for year, starting from the year 2000
- 4 bits for year
- > 5 bits for day in the month
- > 5 bits for hour
- > 6 bits for minutes
- > 5 bits for half of seconds

Example

For date 23/09/2016 15:54:56:

- Year 2016 = bit 0010000
- Month 9 = bit 1001
- Day 23 = bit 10111
- Hour 15 = bit 01111
- Minutes 54 = bit 110110
- Seconds 56 (/2 = 28) = bit 11100

The sequence in bits is "00100001001101110111111011011100", corresponding to the hexadecimal "21377edc", which will be sent as LSB: dc 7e 37 21



MCF88 DATA FRAME FORMAT 1.23

Author: Colognato Stefano

2.2 UART MESSAGE

HOME

name	size [byte]	hex value	meaning
Downlink ID	1 byte	03	Uart
Data	Application related	xx xx	Data to be forwarded, proprietary mcf88 protocol.

2.3 IO MESSAGE

HOME

name	size [byte]	hex value	meaning
Downlink ID	1 byte	04	General message
Option	1 byte	00	Identify an IO message
Enable	4 byte (u32 LSB)	XX XX XX XX	Bit mask of the outputs to be enabled
Disable	4 byte (u32 LSB)	XX XX XX XX	Bit mask of the outputs to be disabled
Ton	16 byte (Optional)	xxxx	2 bytes (LSB) per output (outputs 1 to 8): if ≠ 0, set the activation time (base 100ms) of output[n]

If both the enable and the disable bit are equal to zero, the current status will be sent

Example

Downlink ID: 04 Option: 00 (IO message)

Enable: 01000000 -> 0x01 0x00 0x00 0x00 -> u32 LSB -> 0x00 0x00 0x00 0x01 -> 0x01 -> 00000001b (out #1)

Disable: 00000000 -> No output disable

Payload to reset out#1 040000000000001000000

Downlink ID: 04 Option: 00 (IO message)

Enable: 00000000 -> No output enable

Disable: 01000000 -> 0x01 0x00 0x00 0x00 -> u32 LSB -> 0x00 0x00 0x00 0x01 -> 0x01 -> 00000001b (out #1)

Payload to set out#1 for 5 seconds: 0400010000000000000003200

0x04 = Downlink ID0x00 = Io type

Enable: 01000000 -> 0x01 0x00 0x00 0x00 -> u32 LSB -> 0x00 0x00 0x01 -> 0x01 -> 00000001b (out #1)

Disable: 01000000 -> No output disable

 $0x3200 = Ton\ output[1]\ 0x32\ 0x00 -> LSB -> 0x00\ 0x32 -> 50 * 100ms -> Ton[1] = 5s$

Ton is mandatory only if you want to use the pulse feature



MCF88 DATA FRAME FORMAT 1.23

Author: Colognato Stefano

0x04 = Downlink ID

0x00 = IO type

 $0x050000000 = Bit \ mask \ enable \ output \ 0x05 \ 0x00 \ 0x00 \ 0x00 \ -> \ u32 \ LSB -> 0x00 \ 0x00 \ 0x00 \ 0x05 -> 0x05 -> 00000101b -> \ enable \ output[3]$

0x00000000 = Bit mask disable output-> No output disable

0x0000 = Ton output[1] 0x00 0x00 -> LSB -> 0x00 0x00 -> 0 -> 0 means infinite (as a normal output)

0x0000 = Ton output[2] 0x00 0x00 -> LSB -> 0x00 0x00 -> 0 -> 0 means infinite (as a normal output), in this case unused but mandatory to fill the space

but mandatory to fill the space

 $0x0A00 = Ton\ output[3]\ 0x32\ 0x00 -> LSB -> 0x00\ 0x0A -> 10 * 100ms -> Ton[3] = 1s$

2.4 SET PERIOD

HOME

name	size [byte]	hex value	meaning	
Downlink ID	1 byte	04	General message	
Option	1 byte	01	Identify a SET MAIN PERIOD message. fw release 1.40 and above supports Data size up to 2 byte.	
		04	Identify a SET I/O PERIOD message	
		05	Identify a SET COUNTERS PERIOD message	
Data	1 byte	XX	Set device operation period in minutes (note that some devices have a minimum period, eg MCF-LW12TER 10 min, MCF-LW12VOC 15 min, MCF-LW12TERPM 15 min)	

2.5 METERING REQUEST

HOME

name	size [byte]	hex value	meaning
Downlink ID	1 byte	04	General message
Option	1 byte	02	Identify a METERING REQUEST message. Requires special message metering
Option 2	1 byte	00	

2.6 SET PRESSURE COMPENSATION

HOME

name	size [byte]	hex value	meaning
Downlink ID	1 byte	04	General message
Option	1 byte	03	Identify a SET PRESSURE COMPEN- SATION message
Offset	2 byte	xx xx	Add an offset to the pressure in Pa (LSB) (int with sign) to compensate for the altitude, see following table



Author: Colognato Stefano

meters	Pa	meters	Pa
205	2700	4040	40000
-305	-3700	1646	18300
-244	-3000	1707	18900
-183	-2200	1768	19500
-122	-1500	1829	20100
-61	-700	1890	20700
0	0	1951	21300
U	Ü	2012	21900
61	700	2073	22500
122	1500	2134	23100
183	2200	2195	23700
244	2900	2256	24300
305	3600	2316	24900
366	4300	2377	25500
427	5000	2438	26100
488	5700	2499	26600
549	6400	2560	27200
610	7100	2621	27800
671	7800	2682	28300
732	8500	2743	28900
792	9200	2804	29500
853	9800	2865	30000
914	10500	2926	30600
975	11200	2987	31100
1036	11800	3048	31600
1097	12500	2926	30600
1158	13200	2987	31100
1219	13800	3048	31600
1280	14500		
1341	15100		
1402	15700		
1463	16400		
1524	17000		
1585	17600		



MCF88 DATA FRAME FORMAT 1.23

Author: Colognato Stefano

2.7 THRESHOLDS

HOME

name	size [byte]	hex value	meaning
Downlink ID	1 byte	04	General message
Option	1 byte	06	Identify a THRESHOLDS message
Enable	1 byte	XX	refer to Note 13
Data	132 byte	xxxx	2 bytes (LSB) per threshold (T1h+, T1h-, T1l+, T1l-, T2h+, T2h-, T2l+, T2lT4l-); refer to Note 13

Note 13:

Data are as follow:

- > 1 byte is for thresholds enable:
 - Bit 0: enable threshold high channel 1
 - Bit 1: enable threshold low channel 1
 - Bit 2: enable threshold high channel 2
 - Bit 3: enable threshold low channel 2
 - Bit 4: enable threshold high channel 3
 - Bit 5: enable threshold low channel 3
 - Bit 6: enable threshold high channel 4
 - Bit 7: enable threshold low channel 4
- ➤ 2 bytes LSB for threshold (only one channel in Watt for MCF-LW12PLG and MCF-LW12MET, up to 4 channels in bit for MCF-LW06420, MCF-LW06010 and MCF-LW06424):
 - Channel 1 threshold high +
 - Channel 1 threshold high -
 - Channel 1 threshold low +
 - Channel 1 threshold low –
 - •
 - •
 - Channel 4 Threshold low -



MCF88 DATA FRAME FORMAT 1.23

Author: Colognato Stefano

2.8 SERIAL DATA

HOME

name	size [byte]	hex value	meaning
Downlink ID	1 byte	05	Serial data
Data Option	2 byte	XX XX	Refer to Note 14
Data	033 byte	XX XX	Data received, refer to Note 14.

Note 14:

Data sent to the device are buffered starting with index 0 and sent on the serial port after the last frame.

Data Option is LSB and formatted as follow:

- Bit 0..11: index of the first byte of the current frame
- bits 12..15:
 - o 0x0 standard payload
 - 0x8 last frame of the buffer
 - 0xC last frame of the buffer, <u>data has to be saved into the MCF88 sensor (i.e. Modbus configuration</u> table)
 - o 0x4 one BUFFER DOWNLINK frame missing, offset reports the expected one

Maximum data length is 1024 bytes.

Example

Sample payload:

0500000103F4000400010324010400010334010400010366010200010376010200010380 0521000102000103880102000103900102000103A8010200FF6604000000020301000700 054280000000000000

Downlink ID: 05
Data option: 0000

- Bit 0...11:0x000 first byte index = 0
- Bit 12...15: 0x0 standard payload

Data: 0103F4000400010324010400010334010400010366010200010376010200010380

Downlink ID: 05
Data option: 2100

- Bit 0...11:0x021 first byte index = 33
- Bit 12...15: 0x0 standard payload

Data: 0102000103880102000103900102000103A8010200FF6604000000020301000700

Downlink ID: 05 Data option: 4280

- Bit 0...11:0x042 first byte index = 66
- Bit 12...15: 0x8 last frame of the buffer

Data: 00000000000000



Author: Colognato Stefano

2.9 OFF COMMAND

HOME

name	size [byte]	hex value	meaning
Downlink ID	1 byte	04	General message
Option	1 byte	FF	Identify an OFF message
Option 2	1	00	If it is a battery-powered device, turn off the module, otherwise it will restart it.