JBL

JBL PARTYBOX 1000

SOFTWARE UPGRADE INSTRUCTIONS **October 2019**

JBL is pleased to offer this product upgrade version 64, which improves the performance of your PartyBox 1000 speaker.

This software upgrade improves:

- Optimized Microphone overload issue at Max Volume

Important Note:

This software is specially designed for use with JBL PartyBox 1000.
Use with any other models or brands may cause damage to the product.
DO NOT USE THIS SOFTWARE WITH ANY OTHER PRODUCTS.

Software check/pronounce:

This software upgrade has version: 64
To check if unit requires an upgrade, follow below procedure:

1. Power On the PartyBox 1000 speaker.
2. Press and hold both the "Volume -" & "Bass Boost" buttons simultaneously for 4-5 seconds.
   The unit pronounces software version by voice in ten numbers.
   The first 2 numbers pronounced refer to the software version loaded on the unit.

*As an example, if the following numbers are broadcasted: **64** 31 1 7 1 5 0 7, this means the unit is running software version **64**.*

3. If the software version is 64 (or any number greater), no further action is needed.
4. If the software version is less than 64, then proceed and carry out the upgrade according to the instructions that follow.

System requirements:

- To perform the software upgrade, you will need a USB memory stick with at least 50Mb of available storage capacity and the AC power cord of the unit.
- To install the software upgrade, the actual software file "PB1000_FW_V64_FULL.bin" must be installed into the main root directory of an empty USB memory stick.

INSTALLATION INSTRUCTIONS
PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE PROCEEDING.
Upgrading your PartyBox 1000 speaker is easy, but for the upgrade to work properly, it is important to carefully follow the instructions below. From the moment the update is began (Step 5 below), the entire upgrade procedure may take approximately 6 minutes, and once it begins ***you must complete the entire process in one session***. Please allow sufficient time to complete all the steps.

Attention: Do not cut off the power while updating!

1. Save the "PB1000_FW_V64_FULL.bin" file into the main root directory of a USB memory stick
2. Power Off the unit.
3. Insert the USB-stick into the USB socket placed on the rear side of the Partybox 1000.
4. Power On the PartyBox 1000 and allow it to fully power up.
5. Press and hold the "Volume +" & "Bluetooth" buttons simultaneously for more than 10 seconds until all Top panel LEDs go off, except for the Power button LED - Upgrade is now in progress.

Note: The update is now in progress and takes approximately 6 minutes to complete.
Do not power off the unit. Leave unit alone and allow it to complete the update. During the update, there will be a brief moment when the unit appears to be off (Power LED goes off for a moment). This is normal and part of the update procedure.

6. Once the upgrade has completed, the unit will reboot itself and all LEDs on the top and front panel will come back and resume as normal.
Note, in the event you step away from the PartyBox 1000 speaker during the update and later return to it and are unsure if it is still updating, refer to the top panels DJ Pad and Source LEDs lighting. If all DJ Pad and Source LED lighting is Off, then the update is still in progress. If the DJ Pad and Source LED lighting is On, then this indicates the software update has completed.

Congratulations, your PartyBox 1000 speaker is now upgraded to the latest software version 64.