

# ET Expert Setup Checklist

⚡ For experienced installers. Use this sheet as a **step-by-step verification**. Check each item once confirmed.

## Initial Configuration

**Wrench > Initial Setup > Configuration**

- Factory Reset → DO NOT CONTINUE WITH SETUP UNTIL COMPLETED
- Manufacturer → ET PWM
- Nozzle Spacing → Enter actual spacing
- Total Nozzles (Verify) → Matches detected vs. physical count

## VCM Setup

**Wrench > Initial Setup > VCM Setup**

- Confirm left-to-right order across boom
- Swap VCMs if needed
- Verify with Key Fob → nozzles fire sequentially left-to-right

## Boom/Nozzle Setup

**Wrench > Boom/Nozzle > Nozzle Bounds**

- Valve Diagnostics → Coil Only

**Wrench > Boom/Nozzle > Nozzle Setup > Softboom Setup**

- 60/90 ft. 20" Steel → 4, 9, 16, 24, 30, 38, 45, 50, 54
- 60/90 ft. 15" Steel → 6, 12, 22, 32, 41, 51, 61, 67, 73
- 90 ft. 20" Steel → 6, 12, 18, 24, 30, 36, 42, 48, 54
- 100 ft. 15" Steel → 10, 18, 26, 36, 45, 55, 63, 71, 81
- 100 ft. 20" Steel → 7, 14, 21, 28, 34, 41, 48, 55, 62
- 90 ft. 15" Pommier → 7, 15, 23, 32, 41, 50, 58, 66, 73
- 90 ft. 20" Pommier → 5, 11, 17, 24, 30, 37, 43, 49, 54
- 100 ft. 20" Pommier → 7, 14, 20, 27, 33, 40, 46, 53, 60
- 100 ft. 15" Pommier → 10, 19, 27, 36, 45, 54, 62, 71, 81
- 120 ft. 20" Pommier → 8, 16, 24, 32, 40, 48, 56, 64, 72
- 120 ft. 15" Pommier → 11, 22, 33, 44, 53, 64, 75, 86, 97
- 132 ft. 20" Pommier → 10, 19, 27, 36, 44, 53, 61, 70, 80
- 90 ft. 15" Ceres → 7, 12, 22, 32, 41, 51, 61, 66, 73
- 90 ft. 20" Ceres → 5, 9, 16, 24, 30, 38, 45, 49, 54

- 100 ft. 15" Ceres → 7, 16, 26, 36, 45, 55, 65, 74, 81
- 100 ft. 20" Ceres → 5, 12, 19, 27, 33, 41, 48, 55, 60
- OTHER → Record your settings here:

## **Flow Setup**

**Wrench > Flow > Flowmeter Setup**

- Meter 1 Calibration → Actual calibration number (Pulses/10 GAL)
- Meter 2 Calibration → Actual calibration number (Pulses/10 GAL)

 **Setup Complete** — installer verified all values and configuration.