


## POINT AT FRONT



Point the gimbal towards the front of the drone.

The gimbal will attempt to always point towards the front.